

SE8000 Room Controllers

SE8350 User Interface Guide

Low Voltage Fan Coil Unit (FCU) and Zone Control

Firmware Revision 2.4



Table of Contents

Safety Information	3
Before You Begin.....	4
Section 1	
Introduction	6
User and Integrator Screens	6
Disclaimer	7
HMI Display.....	8
Enter Setup Screen	9
Section 2	
User HMI for Hospitality	11
User HMI for Commercial	12
System Mode	13
Fan Mode Settings	13
Heating Only Configuration	14
Setpoint Adjustment for Cooling Mode.....	14
Setpoint Adjustment for Automatic Mode	15
Other Functions.....	15
Customizable Color Options	16
Section 3	
Network Screens	18
Configuration Screens.....	30
Setpoints Screens	45
Display Screens	47
Service View Screens	51
Test Outputs Screens	60
Language Selection Screens	61
Clock - Schedule Screens.....	62
Automatic Demand Response (ADR) Screen.....	66
Wireless Screens.....	68
LUA Screens	76
Section 4	
Appendix A: Terminal Correspondence	80

Safety Information

IMPORTANT INFORMATION

Read these instructions carefully and look at the equipment to become familiar with the device before trying to install, operate, service or maintain it. The following special messages may appear throughout this bulletin or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of either symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in** death or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in** death or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result in** minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury. The safety alert symbol shall not be used with this signal word.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction, installation, and operation of electrical equipment and has received safety training to recognize and avoid the hazards involved.

Before You Begin

LOSS OF CONTROL

⚠ WARNING

LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical control functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and over travel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of anticipated transmission delays or failures of the link.¹
- Each implementation of equipment utilizing communication links must be individually and thoroughly tested for proper operation before being placed into service.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

ELECTROSTATIC DISCHARGE

NOTICE

STATIC SENSITIVE COMPONENTS

Circuit boards and option cards can be damaged by static electricity. Observe the electrostatic precautions below when handling controller circuit boards or testing components.

Failure to follow these instructions can result in equipment damage.

Observe the following precautions for handling static-sensitive components:

- Keep static-producing material such as plastic, upholstery, and carpeting out of the immediate work area.
- Store static-sensitive components in protective packaging when they are not installed in the drive.
- When handling a static-sensitive component, wear a conductive wrist strap connected to the component or drive through a minimum of 1 megohm resistance.
- Avoid touching exposed conductors and components leads with skin or clothing.

¹ For additional information about anticipated transmission delays or failures of the link, refer to NEMA ICS 1.1 (latest edition), *Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control* or its equivalent

SECTION 1

Introduction


Introduction

This guide shows the user interface instructions for the SE8350 Series Room Controller (RC) firmware **revision 2.4** for users and integrators.

User and Integrator Screens

The SE8350 Room Controller has dynamic screens that show adjustable parameters and read-only status information. Some screens and parameters only show when a corresponding parameter is selected. Some screens only show on models with onboard ZigBee, optional ZigBee add-on module (VCM8000), optional Wi-Fi module (VCM8002) or paired ZigBee wireless sensor end devices (SED). The LUA selection on the Setup screen only shows if a LUA script is uploaded to the Room Controller.

See below legend screen details.



NOTE: When any change is made to a parameter, the value is automatically saved in memory when the next parameter is selected or another screen is opened. This event is true only if a parameter was changed locally on the RC. Making changes through BACnet will not have the same outcome. If changes need to be done remotely through BACnet, use priority 1, 2 or 3, or write to relinquish default (priority 17).

Disclaimer

Standby screen: The Room Controller incorporates TFT-type LCD technology, and therefore, necessary precautions are required to prevent the phenomenon of image retention (residual image) from occurring.


Image retention may occur when a static image is displayed on the screen for a prolonged period of time. This can cause a faint outline of the image to remain visible on the screen when the screen is changed via the user menu, or a different image is uploaded and selected to be displayed. To minimize and prevent image retention, it is recommended to select the **Screen Save** setting on the **Standby screen** selection from the setup menu **Display 1/2**. This setting switches the display during periods of inactivity from the Home Screen.

It is recommended to use a black or medium gray image, or one with light color contrasts as the screen saver to prevent this phenomenon from occurring. If the display still exhibits this phenomenon, loading an all-black or all-medium gray image as the screen saver and displaying it for upwards of 5 hours continuously minimizes this effect.


NOTE: Avoid placing the Room Controller in poorly ventilated areas, or in areas that may create excess heat around the display.

HMI Display

The User Human Machine Interface (HMI) is configurable and allows display functions such as Date, Time, Humidity, CO2 levels, Outdoor Temperature and Setpoint to be enabled or disabled by setting various parameters.




Enter Setup Screen



Touch and hold this point for 3 seconds to enter setup mode

Note: If a configuration/installer password is activated to prevent unauthorised access to the configuration menu parameters, a password entry prompt shows to prevent access to device configuration components.

SETUP 1/2



BACnet MS/TP, Modbus, ZigBee and Wi-Fi network settings (ZigBee network settings appear only if ZigBee feature is available)

Parameter configuration menu


Setpoint settings

Display settings

Status display (Read Only)

Test outputs settings

SETUP 2/2



Select language

Set clock, schedule and occupancy

Automatic Demand Response

Wireless Ecosystem settings (shows only if ZigBee feature is available)

LUA scripting (shows only if LUA script uploaded)

SECTION 2

Customized User HMI Display


User HMI for Hospitality

Hospitality 0




- Setpoint adjustment
- System mode setting
- Fan mode setting
- Local unit scale adjustment
- Local user language
- User help menu

Hospitality 1




- Setpoint adjustment
- System mode setting
- Fan mode setting
- User help menu

Hospitality 2



- Setpoint adjustment
- Local unit scale adjustment
- Local user language
- User help menu


Hospitality 3



- Setpoint adjustment
- User help menu


NOTE: Parameters are model dependent and may not appear on certain models.

Hospitality 4




- Fully locked interface with no user settings

Hospitality 5



- Setpoint adjustment
- System mode setting
- User help menu

Hospitality 6



- Setpoint adjustment
- System mode setting
- Fan mode setting
- Local unit scale adjustment
- User help menu

User HMI for Commercial

Commercial 7

09.26.2012 12:54 PM

Room 1705

Standby  

Indoor °C

23.5°

24.0

- Setpoint adjustment
- System mode setting
- Fan mode setting
- Unoccupied mode overdrive
- User help menu

Commercial 8

09.26.2012 12:54 PM

Room 1705

Standby  

Indoor °C

23.5°

24.0

- Setpoint adjustment
- Unoccupied mode override
- Local user language
- User help menu

Commercial 9

09.26.2012 12:54 PM

Room 1705

Standby  

Indoor °C

23.5°

24.0

- Setpoint adjustment
- Unoccupied mode override
- User help menu

Commercial 10

09.26.2012 12:54 PM

Room 1705

Standby  

Indoor °C

23.5°



- Unoccupied mode override

Commercial 11

09.26.2012 12:54 PM

Room 1705

Standby  

Indoor °C

23.5°

24.0

- Setpoint adjustment
- System mode setting
- Unoccupied mode override
- User help menu

Commercial 12

09.26.2012 12:54 PM



+ 1.5

Humidity 45 %


   

- Offset setpoints adjustment
- System mode setting
- Local user language
- Fan mode setting
- User help menu

NOTE: The day/night setback button appears only in unoccupied mode in the Commercial HMIs 7 to 11. If UI17 input is configured as “override”, the day/night setback button does not show.


NOTE: Parameters are model dependent and may not appear on certain models.

System Mode



Mode	Significance and Adjustments
System mode Off	Off Heating, Cooling and Dehumidification demands are ignored.
System mode Auto	Auto Room Controller automatically toggles between Heating and Cooling modes to satisfy both Heating and Cooling demands. Dehumidification is allowed.
System mode Cool	Cool Room Controller only satisfies Cooling demands, Heating demands are ignored. Dehumidification is allowed.
System mode Heat	Heat Room Controller only satisfies Heating demands, Cooling demands are ignored. Dehumidification is allowed.


Fan Mode Settings



The Fan mode settings displayed on the home screen must be configured in the Fan menu tab of the Configuration menu.

The possible options are **Low, Med, High, Auto, On.**


Heating Only Configuration



Setpoint Adjustment for Cooling Mode

In Cooling mode, the setpoint displayed in the bar is the current occupied cooling setpoint. During occupied setpoint adjustment, the large digits are temporarily used to show occupied cooling setpoint while it is adjusted.

Normal temperature display resumes after setpoint is adjusted and actual occupied cooling setpoint shows in setpoint bar.




Setpoint Adjustment for Automatic Mode

In automatic mode, setpoint showing at the top of the set point bar located directly under the red line represents the actual occupied cooling setpoint.

During occupied setpoints adjustment, large digits are temporarily used to display the occupied Cooling Setpoint or occupied Heating Setpoint. The actual setpoint is dependent on the last effective demand (heating or cooling). The setpoint on top of the blue line represents the actual occupied heating setpoint. The differential between the occupied heating and cooling setpoint is defined by the minimum deadband configuration parameter.

Normal temperature display resumes after setpoints are adjusted and the actual occupied heating and cooling setpoints show in the setpoint bar.




Other Functions


Local humidity shows when RH display is enabled on the setup display screen, from either the internal onboard sensor or a wireless sensor end device selected by the RH sensor parameter on the setup configuration screen.

CO2 shows when CO2 display is enabled on the setup display screen, from either the optional CO2 detection sensor module or a wireless sensor end device selected by the CO2 source parameter on the setup configuration screen.

Outdoor temperature shows when receiving a valid networked outdoor temperature value or a temperature sensor connected to UI23.



Customizable Color Options



White



Green



Blue



Dark Grey



Grey



Pink



Purple



Red



Orange



Black

SECTION 3

Integrator Setup Screens

Network Screens

User can select wired BACnet / Modbus / ZigBee wireless protocol (when ZigBee feature is available).

NOTICE

UPGRADE OF ZIGBEE 2.4 TO 3.0

The upgrade from ZigBee 2.4 to 3.0 will **not** support the Green Power Sensor (SED-CO2-G-5045 or SED-TRH-G-5045). It will therefore need to be recommissioned.


There is also a new "Security Levels" parameter for the Zigbee network (see page 20):

Low (default value) is fully backwards compatible with ZigBee Home Automation 1.2 devices, and therefore compatible with all of our sensors.

Normal (needs to be selected by user) is only compatible with Green Power and ZigBee 3.0 (Leedarson sensors).

If the Normal Security Level is selected with old NYCE or Centralite sensors, they will be removed from the network.

Failure to follow these instructions can result in equipment being disconnected from the network.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Onboard prot. Read Only	Onboard Protocol Onboard ZigBee detection Display Readings: None, ZigBee
Optional prot. Read Only	Optional Protocol Requires ZigBee add-on module (VCM8000) or Wi-Fi module (VCM8002). None: No module detected ZigBee: ZigBee module detected IP: Wi-Fi module detected BAC. IP: Wi-Fi module detected and BACnet/IP enabled Display Readings: None, ZigBee, IP or BAC. IP
Wired protocol Default value: None	Wired Protocol None: No wired protocol configured BAC MSTP: BACnet MS/TP network protocol Modbus: Modbus network protocol Choices: None, BAC MSTP or Modbus

ZIGBEE NETWORK 1/2

The ZigBee Network screen shows only in models with onboard ZigBee or optional ZigBee add-on module.

When creating a ZigBee network, there must be one and only one device with its Node Type set to Coordinator. For a ZigBee network with a single Room Controller (RC), the RC is set as Coordinator to pair with the Sensor End Devices (SED). Setting the RC back to Router will remove the paired SEDs. For a ZigBee network with a Multi-Purpose Manager (MPM) paired to multiple RCs, the MPM is set as Coordinator and the RCs are set as Router. The Coordinator MPM controls the pairing of the Router RCs to the SEDs

Note: Before pairing any ZigBee devices, the network must first be created by the Coordinator.

1/2 ZigBee Network	
Node type	Router
PAN ID	0
Channel	10
Security	Low
Network Status	No NWK
Permit join	Off

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Node type Default: Router	Node Type Sets device to act as Router or Coordinator in a network. Coord.: Creates the network and manages the binding of wireless devices. Router: Joins a network created by a coordinator (Coordinator permit join must be set to 'ON'). Choices: Coord. or Router
PAN ID Default value: 0	ZigBee Pan ID Personal Area Network Identification that links specific Room Controllers to specific ZigBee coordinators. For every Room Controller reporting to a coordinator, set the SAME PAN ID value both on the coordinator and the Room Controller. Note: The default value of 0 is NOT a valid PAN ID and causes ZigBee to be disabled. Range: 1 to 65535
Channel Default value: 10	ZigBee Channel The channel (wireless frequency) on which the ZigBee network transmits and receives data. The channel of the Coordinator must match that of the routers to exchange data. The default value of 10 is NOT a valid channel and causes ZigBee to be disabled. The valid range of available channels is from 11 to 25. Using channels 15, 20, and 25 is recommended. Channel 25 is considered as being the best one because it is furthest from the Wi-Fi channels. Range: 10 to 25

Configuration Parameters Default Value	Significance and Adjustments
Security Default value: Low	Security Levels Note: Changing between ZigBee Security levels does not require re-creating the ZigBee network, or re-commissioning sensors. Low: Disables new security features in ZigBee 3.0 to be fully backwards compatible with ZigBee Home Automation 1.2 devices, and therefore compatible with all of our sensors. Normal: Enables the typical new features of ZigBee 3.0. This means that legacy ZigBee Home Automation 1.x devices cannot join a Normal security network. Compatible with the following sensors: • SED-WDS-P-5045 • SED-WDC-G-5045 • SED-CMS-P-5045 • SED-WMS-P-5045 • SED-MTH-G-5045 • SED-TRH-G-5045 • SED-C02-G-5045 Important! Selecting the Normal Security option will result in the removal of legacy sensors from the network. Choices: Low or Normal
Network Status Read Only	ZigBee Network Status Shows the current status of the ZigBee network. No NWK: ZigBee configured but no network joined Joined: ZigBee network joined Online: Communicating (Exchanging data) Display Readings: No NWK, Joined, Online
Permit join Default value: Off	Permit Join Changing this value to “Off” on the Coordinator prevents any new ZigBee devices from joining the network. Permit join can be On/Off when the Room Controller is a Coordinator, however the parameter is read only when the Room Controller is a router. If not set to off manually the Permit join will stay On for 3 hours. Choices: On or Off

ZIGBEE NETWORK 2/2

2/2 ZigBee Network

COM address

254

Short address

0x0000

IEEE address:
00124B0018E25296

ZigBee revision:
30.0.0-13-8c3477d

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
COM address Default value: 254	COM Address Room Controller networking address. For wireless models, the use of the COM address is not mandatory. The COM address is an optional way to identify a device on the network and is recommended if used with an MPM. It is Mandatory for BACnet. Range: 0 to 254
Short address Default value: 0 Read Only	ZigBee Short Address The unique ZigBee short address is generated once a wireless device joins a ZigBee network.
IEEE address Read Only	IEEE Address The extended IEEE address (MAC address) is a unique worldwide identifier of the onboard ZigBee or optional ZigBee add-on module.
ZigBee revision Read Only	Communication Module Revision Number Shows the ZigBee firmware revision number.

BACNET NETWORK SETTINGS

BACnet network screen shows when BACnet MS/TP is selected in wired protocol parameter.

1/2 BACnet Network

COM address	254
Network units	SI
Network lang.	English
Baud rate	Auto
BACnet status	Offline
BACnet PRate	4

PARAMETER DETAILS


Configuration Parameters Default Value	Significance and Adjustments
COM address Default value: 254	Communication Address Room Controller networking address. Default value of 254 disables BACnet communication for the Room Controller. Range: 0 to 254
Network units Default value: SI	Measurement Units Network units transmitted over the BACnet network. NOTE: Use the Temperature scale parameter to change the display units locally on the Room Controller. Imperial: Network units shown as Imperial units. SI: Network units shown as International Metric units. Choices: Imperial or SI
Network lang. Default value: English	Network Language Network language/object names transmitted over network. Choices: English, French or Spanish
Baud rate Default value: Auto	BACnet Baud Rate Leave the value at Auto unless instructed otherwise as this automatically detects BACnet baud rate. Choices: Auto, 115200, 76800, 57600, 38400, 19200 and 9600
BACnet status Read Only	BACnet Status Read Only value shows if a BACnet Network is detected or not. Display Readings: Online or Offline
BACnet PRate Default value: 4	BACnet Poll Rate Rate at which a BACnet stack is processed, in milliseconds. Range: 1 to 5.

BACNET INSTANCE NUMBER

The default BACnet instance number is generated by the model number and COM address of the Room Controller. For example, the instance number of a SE8350U5B00 with a COM address of 57 is generated as “83057”.

The default instance number appears first. To change the instance number, use number pad and press **Accept and save**.

Tap “R” icon to reset to automatic instance addressing.



MODBUS NETWORK SETTINGS

Modbus network screen shows when Modbus is selected in wired protocol parameter.

The image shows a 'Modbus Network' configuration screen. It has a title bar 'Modbus Network'. Below it are four rows of settings, each with a label and a value in a button-like field:

- COM address: 254
- Network units: SI
- Baud rate: 19200
- Parity: None


At the bottom of the screen are five navigation icons: a circular arrow (refresh), a curved arrow (back), a house icon (home), a downward arrow (down), and an upward arrow (up).

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
COM address Default value: 254	Communication Address Valid address range is set at 1 to 247 and each Modbus device must have a unique address. Other values not recommended for Modbus. Default value of 254 disables Modbus communication for the Room Controller. Range: 0 to 254
Network units Default value: SI	Measurement Units Network units transmitted over the BACnet network. NOTE: Use the Temperature scale parameter to change the display units locally on the Room Controller. Imperial: network units shown as Imperial units. SI: network units shown as International Metric units. Choices: Imperial or SI
Baud rate Default value: 19200	Modbus Baud Rate Automatically detects Modbus baud rate. Choices: 57600, 38400, 19200, 9600 and 4800
Parity Default value: Even	Parity Determines how the parity bit of the character's data frame is set to detect any errors in the sent/receives frame. Choices: None, Odd and Even

Wi-Fi 1/5


The Wi-Fi Network screen shows only in models with optional Wi-Fi module (VCM8002).



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Module status Read Only	Module Status Displays the current status of the Wi-Fi module. It would normally display Ready when the Wi-Fi module is operational. Status value: Offline, Booting, Initializing, Ready, Fail

Wi-Fi 2/5



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Access point Default value: Disabled	Access Point On this screen the access point can be enabled or disabled as needed. Choices: Enabled or Disabled

Wi-Fi 3/5

SSID of the building Wi-Fi network that the device is connected to

3/5 Wi-Fi Network

Wi-Fi status

Online

Signal strength

75%

SMTP status

Online

SSID:

Your Wi-Fi Network

IP address:

192.168.171.40 (dhcp)

When connected to the building Wi-Fi network shown above, browse to this IP address to access the Configuration Web Page

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Wi-Fi status Read Only	Wi-Fi Status When not connected to a Wi-Fi network the status remains Idle. Once the RC is on your preferred Wi-Fi network, the status will be displayed as Ready, or Online if it has an internet connection. Status value: Idle, Connected, Associate, Config, Ready, Online, Disconn, Failure
Signal strength Read Only	Signal Strength Signal strength of the Wi-Fi network. Range: 0 to 100%
SMTP status Read Only	SMTP Status Status of the email SMTP server. Status value: Disabled, Offline, Online


Wi-Fi 4/5



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Facility Expert Read Only	Facility Expert Shows whether the Facility Expert system is Disabled or Enabled. Status value: Disabled or Enabled
Status Read Only	Status Shows the current status of the Facility Expert system. Range: Disabled, Offline, Connect., Online, Failure, Unknown.

Wi-Fi 5/5




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Factory reset? Default value: No	Erase All Accepting Yes for both and then tapping 'Push to accept' will restore the Wi-Fi module to the factory settings, erase all configuration data and revert the Wi-Fi module firmware to the factory firmware version. NOTES: • If you lose or forget your password for the Configuration Web Page, you must do a Factory Reset of the Wi-Fi module. • If your Wi-Fi module was connected to Facility Expert, you will need to contact your Facility Expert Administrator before the device can be reconnected after a Factory Reset.
Are you sure? Default value: No	

Wi-Fi BACNET NETWORK SETTINGS

BACnet network screens are shown when the wired protocol is set to BACnet or a Wi-Fi module is installed with BACnet/IP enabled. Only one BACnet protocol can be used at a time, either the wired protocol BACnet MS/TP (BACnet Network screens), or the Wi-Fi BACnet IP (Wi-Fi screens).



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Network units Default value: SI	Measurement Units Network units transmitted over the BACnet network. NOTE: Use the Temperature scale parameter to change the display units locally on the Room Controller. Imperial: Network units shown as Imperial units. SI: Network units shown as International Metric units. Choices: Imperial or SI
Network lang. Default value: English	Network Language Network language/object names transmitted over network. Choices: English, French or Spanish
Port Default value: 0 Read Only	Port The unique short address of Wi-Fi BACnet IP

BACNET INSTANCE NUMBER

The default BACnet instance number is generated by the model number and COM address of the Room Controller. For example, the instance number of a SE8350U5B00 with a COM address of 57 is generated as "83057".

The default instance number appears first. To change the instance number, use number pad and press **Accept and save**.

Tap "R" icon to reset to automatic instance addressing.

Configuration Screens

CONFIGURATION 1/9

1/9 Configuration

UI16 config	None
UI17 config	None
UI19 config	None
Occupancy src	Motion
Smart recovery	Off
Setpoint func.	Attach SP

↶
↷
🏠
▼
▲

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
UI16 config Default value: None	Universal Input Configuration No. 1 None: No function will be associated with the input. Input can be used for remote network monitoring. Rem NSB: Remote night setback (NSB) timer clock input. The scheduling gets set as per the binary input and provides low cost setback operation via a dry contact Motion NO and Motion NC: Advanced PIR occupancy functions using a Normally Open (NO) or Normally Closed (NC) remote PIR motion sensor. Window: Forces system to disable any current heating or cooling action by Room Controller when window is open. Choices: None, Rem NSB, Motion NO, Motion NC, Window
UI17 config Default value: None	Universal Input Configuration No. 2 None: No function associated with input Door Dry: Room Controller goes to standby mode when door is opened then closed followed by no presence detection for the next 10 seconds if the local PIR is used in this application. The "Occupancy command" in the Options screen must be set to "Local Occupancy" and "Occupancy Source" must be set to "Motion". Override: A closed contact forces the Room Controller to go in occupied mode. An open contact keeps the current occupancy mode. Filter: backlit flashing filter alarm shows on the Room Controller screen when input is energized Service: backlit flashing Service alarm shows on Room Controller screen when input is energized. Choices: None, Door Dry, Override, Filter and Service

Configuration Parameters Default Value	Significance and Adjustments
UI19 config Default value: None	Universal Input Configuration No. 3 None: no function associated with input though input can be used for remote network monitoring COC/NH: change over dry contact normally heat. Used for hot/cold water or air change over switching in 2-pipe systems COC/NC: change over dry contact normally cool. Used for hot/cold water or air change over switching in 2-pipe systems COS: change over sensor. Used for hot/cold water or air changeover switching in 2 pipe systems Choices: None, COC/NH, COC/NC and COS
Occupancy src Default value: Motion	Occupancy Source Motion: Occupancy status received from motion sensor. Schedule: Occupancy status determined by the schedule. Mot. Occ: Occupied when scheduled occupied AND when motion is detected. Mot. Unoc: Occupied when scheduled occupied OR when motion is detected. Choices: Motion, Schedule, Mot. Occ., Mot. Unoc.
Smart recovery Default value: Off	Enable Smart Recovery Off: No smart recovery. The occupied schedule time is the time at which the system will restart. On: Smart recovery active. The occupied schedule time is the time at which the desired occupied temperature will be attained. The Room Controller automatically optimizes the equipment start time. In any case, the latest a system will restart is 10 minutes prior to the occupied period time. Smart recovery is automatically disabled if BI16 is configured to remote NSB. Choices: Off or On
Setpoint func. Default value: Dual SP	Setpoint Function Local setpoint settings to set the local setpoint interface for the User. Dual SP: "Minimum" Deadband, Heat and Cool Setpoints can be adjusted independently. Attach SP: "Fixed" Deadband in occupied mode, Heat and Cool setpoints always follow each other, separated by Deadband value (acts like a single setpoint). Choices: Dual SP or Attach SP

CONFIGURATION 2/9

2/9 Configuration

Mode button	Normal
Auto mode	Enabled
Standby mode	Absolute
Standby diff.	2.0 °C
Fan cont. heat	On

↶
↷
🏠
▼
▲

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Mode button Default value: Normal	Mode Button Changes the behavior of the system mode button functionality and hides/shows temperature setpoints on main screen. Normal: System mode button switches between 'Off', 'Auto', 'Cool' and 'Heat'. Also displays temperature Setpoints on main screen. Off-Auto: System mode button switches between 'Off' and 'Auto'. Hides temperature Setpoints on main screen. NOTE: Setting 'Mode button' to 'Off-Auto' forces the 'Setpoint func.' parameter to 'Attach SP'. Choices: Normal or Off-Auto
Auto mode Default value: Disabled	Auto Mode Enable Enables auto function for the mode button. For sequences 2, 4, and 5 only. Enabled: auto active (Off-Cool-Heat-Auto) Disabled: auto not active (Off-Cool-Heat) Choices: Enabled or Disabled
Standby mode Default value: Absolute	Standby Mode Configuration Standby setpoints used for control. Absolute: Standby entered values are used for standby mode. Offset: Occupied setpoints +/- Standby diff. used for standby mode. Choices: Absolute or Offset

Configuration Parameters Default Value	Significance and Adjustments
Standby diff. Default value: 4°F (2°C)	Standby Temperature Differential When Standby mode is set to 'offset', standby setpoints are calculated as follows: Standby cool: Cool setpoint + Standby diff. Standby heat: Heat setpoint - Standby diff. Range: 1 to 5°F (0.5 to 2.5°C)
Fan cont. heat Default value: On	Fan Control in Heating Mode Configures the operation of the fan when system is heating. On: Fan on Off-Auto: Fan off if fan mode is auto Off-All: Fan off Choices: On, Off-Auto or Off-All

CONFIGURATION 3/9

3/9 Configuration

Fan menu	L-H-A
Auto fan func.	AS
Fan type	ECM
ECM low volt.	2.2 Vdc
ECM med volt.	6.0 Vdc
ECM high volt.	8.6 Vdc

↶
↷
🏠
▼
▲

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Fan menu Default value = On-Auto	Fan Sequence Fan Sequence configuration applies to “3 speed” and “ECM” fan type The selected fan sequence in this menu dictates the Fan button options displayed on the Home screen of the room controller. On-Auto: Single Speed configuration. Auto selection will activate fan on demand. On selection will keep the fan On in occupied, standby and override mode, and will activate fan based on demand in unoccupied mode. L-M-H: 3-Speed configuration L-H: 2-Speed configuration L-M-H-A: 3-Speed configuration with Auto fan speed. Auto Mode operation is dependent on Auto Fan parameter. L-H-A: 2-Speed configuration with Auto fan speed mode. Auto Mode operation is dependent on Auto Fan parameter. Choices: On-Auto, L-M-H, L-H, L-M-H-A and L-H-A
Auto fan func. Default value: AS	Automatic Mode Fan Function Fan Sequence configuration applies to “3 speed” and “ECM” fan type Auto Speed Fan Mode operation for Fan Menu (L-M-H-A) or (L-H-A). AS: In Occupied, Standby and Override modes, the Fan stays ON at low speed even if there is no demand for Heating or Cooling. In Unoccupied mode the Fan turns Off when there is no demand for Heating or Cooling. AS/AD: In any Occupancy mode, the Fan turns Off all speeds when there is no demand for Heating or Cooling. Choices: AS or AS/AD

Configuration Parameters Default Value	Significance and Adjustments
Fan type Default value: 3 speed	Fan Type Fan type configuration determines the fan control method for the fan coil unit 3 Speed: Fan control using 3 binary outputs (Low, Medium, High) ECM: Fan control using 0-10 Vdc Modulating output. Choices: 3 speed or ECM
ECM low volt. Default value: 2.2 Vdc	Point only displayed if "Fan type" is set to "ECM" Voltage to be applied on 0-10 Vdc output when Low fan speed is selected. The points are configurable in units of 0.1 Vdc Range: 2.0 to 4.0 Vdc
ECM med. volt. Default value: 6.0 Vdc	Point only displayed if "Fan type" is set to "ECM" Voltage to be applied on 0-10 Vdc output when Medium fan speed is selected. The points are configurable in units of 0.1 Vdc Range: 4.1 to 7.0 Vdc
ECM high volt. Default value: 8.6 Vdc	Point only displayed if "Fan type" is set to "ECM" Voltage to be applied on 0-10 Vdc output when High fan speed is selected. The points are configurable in units of 0.1 Vdc Range: 7.1 to 10.0 Vdc

CONFIGURATION 4/9

4/9 Configuration

Standby time	0.5 hrs
Unocc. time	0.0 hrs
Temp. occ. time	2.0 hrs
Deh. hysteresis	5 %RH
Deh. max. cool	100%
Deh. lockout	Enabled

↶
↷
🏠
▼
▲

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Standby time Default: 0.5 hours	Standby Time Time between the moment where the PIR cover detects last movement in the area, and the time which the Room Controller stand-by setpoints become active. Note: This parameter is not active when the “Door” function is used (wired or wireless). Range: 0.5 to 24.0 hours (0.5 hour increments)
Unocc. time Default: 0.0 hours	Unoccupied Time Time between the moment where the Room Controller toggles to stand-by mode, and the time which the Room Controller unoccupied mode and setpoints become active. Note: Default value of 0.0 hours disables the unoccupied timer. This prevents the Room Controller from being able to switch from stand-by mode to unoccupied mode when PIR functions are used. Range: 0.0 to 24.0 hours (0.5 hour increments)
Temp. occ. time Default value: 2.0 hours	Temporary Occupancy Time The time the Room Controller stays in override mode before reverting back to unoccupied mode. When the Room Controller is in unoccupied mode, pressing the on-screen Override icon or closing the contact on UI17, configured as “Remote Override”, sets the Room Controller to Override mode for defined time period, and uses the Occupied Cooling and Heating setpoints. Range: 0.0 to 24.0 hours

Configuration Parameters Default Value	Significance and Adjustments
Deh. hysteresis Default value: 5 % RH	Humidity Control Hysteresis Used only if dehumidification sequence is enabled. Range: 2 to 20% RH
Deh. max. cool. Default value: 100%	Dehumidification Maximum Cooling Limit Maximum cooling valve position when dehumidification is enabled. This can be used to balance smaller reheat loads installed in regards to the capacity of the cooling coil. Range: 20 to 100%
Deh. lockout Default value: Disabled	Dehumidification Lockout Enables or disables dehumidification based on central network requirements from the BAS front end. Enabled: Dehumidification Authorized Disabled: Dehumidification Not Authorized Choices: Enabled or Disabled

CONFIGURATION 5/9

5/9 Configuration

CPH	4
Ctrl. type out1	Floating
Ctrl. type out2	Same as 1
BO8 out time	15 min.
BO8 aux. config	Reheat
Floating time	1.5 min

↶
↷
🏠
▼
▲

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
CPH Default value: 4	Cooling Output Cycles Per Hour CPH is used to “modulate” On/Off outputs controlling equipment such as compressors. When the Room Temperature is within the Proportional Band, the output performs 3 or 4 CPH. A higher CPH represents a higher accuracy of control at the expense of wearing mechanical components faster. Note: The CPH does not limit the number of Cycles Per Hour. It is limited by the “Anti short cycle” parameter. 4 CPH is typical for Rooftop applications. Range: 3 to 8 CPH
Ctrl. type out1 Default value: On/Off	Control Output for FCU Valves Defines type of control output for type of valves installed for the FCU application 0-10V DA: Direct Acting analog heating output signal for modulating control of 2-10 Vdc valves. DA = 0 to 100% = 0 to 10 Vdc 0-10V RA: Reverse Acting analog heating output signal for modulating control of 2-10 Vdc valves. RA = 0 to 100% = 10 to 0 Vdc On/Off: normally opened or normally closed 24 VAC 2 position valves Floating: modulating 3 wires control of 24 VAC floating valves Choices: 0-10V DA, 0-10V RA, On/Off and Floating
Ctrl. type out2 Default value: Same as 1	Control Output for FCU Valves Defines type of control output for type of valves installed for the FCU application 0-10V DA: Direct Acting analog heating output signal for modulating control of 2-10 Vdc valves. DA = 0 to 100% = 0 to 10 Vdc 0-10V RA: Reverse Acting analog heating output signal for modulating control of 2-10 Vdc valves. RA = 0 to 100% = 10 to 0 Vdc Same as 1: On/Off: normally opened or normally closed 24 VAC 2 position valves Floating: modulating 3 wires control of 24 VAC floating valves Choices: 0-10V DA, 0-10V RA, Same as 1, On/Off and Floating

Configuration Parameters Default Value	Significance and Adjustments
BO8 out time Default value: 15 min.	BO8 Aux Output Time Base Sets reheat output time base. Valid only if reheat sequences are enabled. Choices: 10 sec. or 15 min.
BO8 aux. config Default value: Reheat NO	BO8 Aux Output Configuration Aux contact function used for reheat if sequence is set to use BO8 for reheat through network or local. Output directly follows occupancy of Room Controller. Reheat NO: Contact closes on call for reheat, used for Normally Closed Valve or heat relay. Reheat NC: Contact opens on call for reheat, used for Normally Opened Valve. Aux NO: Occ or St-By = Contact Closed / Unoccupied = Contact Opened Aux NC: Occ or St-By = Contact Opened / Unoccupied = Contact Closed. Output to follow directly main occupancy and Fan on command. Typically used for 2 position fresh air damper applications. Aux F&NO: Occ or St-By & Fan On = Contact Closed / Unoccupied and Fan On or Off = Contact Opened Aux F&NC: Occ or St-By & Fan On = Contact Opened / Unoccupied and Fan On or Off = Contact Closed Choices: Reheat NO, Reheat NC, Aux NO, Aux NC, Aux F&NO and Aux F&NC
Floating Time Default value: 1.5 min	Floating Actuator Timing Floating actuator stroke timing value. Maximum stroke time of floating valve actuator. Range: 0.5 to 9.0 minutes (0.5 minute increments)

CONFIGURATION 6/9

6/9 Configuration

Prop. band	3.0
No. of pipes	2
Operation seq.	Heat only
Purge sample	2.0 hrs
Purge open	2 min
Temp. sensor	Wired

↶
↷
🏠
✓
⬆

PARAMETER DETAILS

Configuration Parameters	Default Value	Significance and Adjustments																															
Prop. band Default value: 3.0		Proportional Band Setting																															
		Adjusts proportional band used by Room Controller PI control loop.																															
		Note: Default value of 3 gives satisfactory operation in most normal installation cases. The use of a superior proportional band different than the factory value is normally warranted in applications where Room Controller location is problematic and leads to unwanted cycling of the unit. A typical example is a wall mounted Room Controller installed between return and supply air feeds and is directly influenced by the supply air stream of unit.																															
		Range: 3.0 to 10.0																															
		<table><tr><th>Value</th><th colspan="2">Effective Proportional Band</th></tr><tr><td></td><th>Fahrenheit</th><th>Celsius</th></tr><tr><td>3.0</td><td>3</td><td>1.2</td></tr><tr><td>4.0</td><td>4</td><td>1.7</td></tr><tr><td>5.0</td><td>5</td><td>2.2</td></tr><tr><td>6.0</td><td>6</td><td>2.8</td></tr><tr><td>7.0</td><td>7</td><td>3.3</td></tr><tr><td>8.0</td><td>8</td><td>3.9</td></tr><tr><td>9.0</td><td>9</td><td>5.0</td></tr><tr><td>10.0</td><td>10</td><td>5.6</td></tr></table>	Value	Effective Proportional Band			Fahrenheit	Celsius	3.0	3	1.2	4.0	4	1.7	5.0	5	2.2	6.0	6	2.8	7.0	7	3.3	8.0	8	3.9	9.0	9	5.0	10.0	10	5.6	
Value	Effective Proportional Band																																
	Fahrenheit	Celsius																															
3.0	3	1.2																															
4.0	4	1.7																															
5.0	5	2.2																															
6.0	6	2.8																															
7.0	7	3.3																															
8.0	8	3.9																															
9.0	9	5.0																															
10.0	10	5.6																															
No. of pipes Default: 2		Number of Pipes																															
		Defines the type of system installed.																															
		Choices: 2 or 4																															

Configuration Parameters Default Value	Significance and Adjustments
Operation seq. Default: Heat only	Sequence of Operation Selects the initial sequence of operation required by the installation type and the application. Cool only: cooling only Heat only: heating only Cool-rht: cooling with reheat Heat-rht: heating with reheat Cool/heat: cooling and heating Cl/ht-rht: cooling and heating with reheat When "Pipe Number" is set to 2 and UI19 is set to COC-NH, COC-NC or COS the "Sequence of operation" is as follows: • "Cool only" or "Heat only" will be determined by the UI19 contact status or sensor temperature. • For 2-Pipe application (no reheat): set "Sequence of operation" to "Cool only" or "Heat only" • For 2-Pipe application (with reheat): set "Sequence of operation" to "Cool-rht" or "Heat-rht" Choices: Cool only, Heat only, Cool-rht, Heat-rht, Cool/heat and Cl/ht-rht
Purge sample Default: 2.0 hrs	Purge Sample Period Time interval between valve samples. Will open valve for a short period adjusted by "Purge open" parameter to sample pipe temperature to decide between heating or cooling mode. Adjustable: 0.0 to 4.0 hours (0 hours disables the function)
Purge open Default: 2 min	Purge Open Time the valve opens to sample pipe temperature to decide between heating or cooling mode. Adjustable: 1 to 3 minutes
Temp. sensor Default value: Wired	Room Temperature Sensor Sets the source of the indoor room temperature. This parameter allows the user to designate either the Room Controller or any of the paired wireless devices that support temperature to act as the source for the room temperature. Wired: sets the thermistor connected to UI20 (RS) as the source to report room temperature. Internal: sets the Room Controller as the source for the room temperature. WL 1 to WL 20: sets the selected ZigBee wireless device as the source for the room temperature. Only one device can be selected. Note: The Room Controller uses the internal temperature sensor only if the UI20 (RS) terminal is empty. If a valid temperature sensor is connected to the UI20 terminal, the Room Controller will use the sensor as the control point. Disconnecting the sensor, or if the sensor is faulty, the Room Controller will automatically revert to its internal temperature sensor. Choices: Wired, Internal and WL 1 to WL 20

CONFIGURATION 7/9

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Main password Default value: 0	Main Password Sets a protective access password to prevent unauthorized access to configuration menu parameters. A default value of "0" will not prompt for a password or lock access to the configuration menu. Range: 0 to 9999.
User password Default value: 0	User Password Sets a protective access password to prevent User unauthorized access to main screen adjustments. A default value of "0" will not prompt for a password. Range: 0 to 9999.
Schedule menu Default value: Enabled	Schedule Menu Toggles activation of schedule menu direct access. Enabled: Schedule Menu is directly accessible from the main screen via a touch in the upper corner. Disabled: Schedule Menu can only be accessed through the Setup Menu screens. En.no.clk: Schedule Menu is directly accessible from the main screen via a touch in the upper corner. Clock does not show. Dis.no.clk: Schedule Menu can only be accessed through the Setup Menu screens. Clock does not show. Choices: Enabled, Disabled, En.no.clk and Dis.no.clk

CONFIGURATION 8/9

8/9 Configuration

Calib. temp.

0.0 °C

Calib. humid.

0.0 %RH

RH sensor

Internal

CO2 source

Local

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Calib. temp. Default value: 0°F (0°C)	Calibration Room Temperature Sensor Room temperature sensor calibration. Offset can be added or subtracted to actual displayed room temperature. Range: ± 5.0°F (± 2.5°C)
Calib. humid. Default value: 0.0 %RH	Calibrate Humidity Sensor Offset that can be added or subtracted to actual displayed humidity. Range: ± 15.0% RH
RH sensor Default value: Internal	Relative Humidity Sensor Sets the source of the indoor room humidity. This parameter allows the user to designate either the Room Controller or any of the paired wireless devices that support humidity to act as the source for the room humidity. Internal: Sets the Room Controller as the source for the room humidity. WL 1 to WL 20: Sets the selected ZigBee wireless device as the source for the room humidity. Only one device can be selected. Choices: Internal and WL 1 to WL 20
CO2 source Default value: Local	CO2 Sensor Source Sets the source of the indoor CO2. This parameter allows the user to designate either the optional CO2 detection sensor module (VCM8001) or any of the paired wireless devices that support CO2 to act as the source for the room CO2. None: CO2 source disabled. Local: Sets the optional CO2 detection sensor module as the source for the room CO2. WL 1 to WL 20: Sets the selected ZigBee wireless device as the source for the room CO2. Only one device can be selected. Choices: None, Local and WL 1 to WL 20

CONFIGURATION 9/9




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Erase all? Default value: No	Erase All Accepting Yes for both and then tapping 'Push to accept' returns all values to the factory default settings with the exception of the following: • COM address • Network Units • Network Language • Baud Rate • BACnet Instance • Device Name • Screen Contrast • Lua Script Note: Node type in ZigBee Network screen returns to default value (Router).
Are you sure? Default value: No	

Setpoints Screens

SETPOINTS 1/2



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Unocc. cool Default value: 80°F (27°C)	Unoccupied Cool Setpoint Cooling Temperature setpoint used by the Room Controller when in Unoccupied mode. Range: 54 to 100°F (12.0 to 37.5°C)
Standby cool. Default value: 78°F (25.5°C)	Standby Cooling Setpoint Cooling Temperature setpoint used by the Room Controller when in Standby mode. Range: 54 to 100°F (12.0 to 37.5°C)
Occ. cool Default value: 75°F (24°C)	Occupied Cool Setpoint Cooling Temperature setpoint used by the Room Controller when in Occupied or Override mode. Range: 54 to 100°F (12.0 to 37.5°C)
Occ. heat. Default value: 72°F (22°C)	Occupied Heating Setpoint Heating Temperature setpoint used by the Room Controller when in Occupied or Override mode. Range: 40 to 90°F (4.5 to 32.0°C)
Standby heat. Default value: 69°F (20.5°C)	Standby Heating Setpoint Heating Temperature setpoint used by the Room Controller when in Standby mode. Range: 40 to 90°F (4.5 to 32.0°C)
Unocc. heat. Default value: 62°F (17°C)	Unoccupied Heating Setpoint Heating Temperature setpoint used by the Room Controller when in Unoccupied mode. Range: 40 to 90°F (4.5 to 32.0°C)

SETPOINTS 2/2

2/2 Setpoints

Default heat	22.0 °C
Min. deadband	1.5 °C
Max. heating	32.0 °C
Min. cooling	12.0 °C
Dehum. SP	50.0 %RH

↶
↷
🏠
▼
▲

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Default heat Default value: 72°F (22°C)	Default Heating Setpoint Used for hospitality applications in stand-alone mode only to reset the occupied setpoints when a new guest enters the room. When the Room Controller is in unoccupied mode, any movement detected by a wired, wireless or local PIR sensor changes the occupancy mode to occupied modes and uses the “Default Heating Setpoint” as the new occupied setpoints. NOTE: This functionality is only valid when Stand-by mode = Offset and “Setpoint Func” is set to “Attached”. Range: 65 to 80°F (18.5 to 26.5°C)
Min. deadband Default value: 3°F (1.5°C)	Minimum Deadband Temperature offset between the Cooling and Heating setpoints to ensure that Cooling setpoint is always warmer than the Heating setpoint. Cooling setpoint ≥ (Heating setpoint + Deadband) Range: 2 to 5°F (1.0 to 2.5°C)
Max heating Default value: 90°F (32°C)	Heating Setpoint Limit Maximum Occupied, Unoccupied, Standby and Override Heating setpoints limit. Range: 40 to 90°F (4.5 to 32.0°C)
Min. cooling Default value: 54°F (12°C)	Cooling Setpoint Limit Minimum Occupied, Unoccupied, Standby and Override Cooling setpoint limit. Range: 54 to 100°F (12.0 to 37.5°C)
Dehum. SP Default value: 50%RH	Dehumidification Setpoint Used only if dehumidification sequence is enabled. Range: 30 to 95% RH

Display Screens

DISPLAY 1/2

1/2 Display

User HMI	0
Color	White
Main display	Temp.
Standby screen	No
Lock screen	No
Contrast	0

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
User HMI Default value: 0	User HMI Sets layout of icons on the home screen for various applications. Refer to Customized screen for more information. Range: 0 to 12
Color Default value: White	HMI Color Change background color of the display screen. Choices: White, Green, Blue, Grey or Dark Grey, Pink, Purple, Red, Orange, Black
Main display Default value: Temp.	Main Display Shows temperature or setpoint on main display. Choices: Temperature or Setpoint
Standby screen Default value: No	Standby Screen When the device is left unattended for 150 seconds, the standby image will appear. A custom image can be uploaded using the Uploader Tool. No: No Stand by image (Screen dims when no motion is detected) Yes: Stand by Image is displayed after 150 seconds Occ. only: Standby image displays after 150 seconds. Screen turns off after 30 minutes only in occupied or override mode. Screen: Standby image displays after 150 seconds. Screen turns off after 30 minutes only in unoccupied or standby mode Choices: No, Yes, Occ. Only or Screen

Configuration Parameters Default Value	Significance and Adjustments
Lock screen Default value: No	Lock Screen Prevents the user from accessing the Room Controller until a password is entered. Screen lockout starts 150 seconds after no activity on the Room Controller (when standby image appears). This functionality is enabled only if the below conditions are met: • Standby image loaded • Standby Screen = "Yes" or "Screen" • User Password = not 0 Choices: No or Yes
Contrast Default value: 0	Contrast Control screen contrast and brightness. Range: -5 to 5

DISPLAY 2/2

2/2 Display

Language	English
Units	°C
Low backlight	60 %
Night backlight	5 %
RH display	Disabled
CO2 display	Disabled

↶
↷
🏠
▼
▲

PARAMETER DETAILS


Configuration Parameters Default Value	Significance and Adjustments
Language Default value: English	Display Language Select language for main display. Choices: English, French, Spanish, Chinese, Russian, Arabic, Bulgarian, Czech, Danish, Dutch, Finnish, German, Hebrew, Hungarian, Indonesian, Italian, Japanese, Norwegian, Polish, Portuguese, Slovak, Swedish and Turkish
Units Default value: °C	Temperature Scale Changes the local display units. Refer to Network Units to change the network units broadcasted over the network. Choices: °C for SI or °F for Imperial.
Low backlight Default value: 60%	Low Backlight Sets display backlight intensity. This feature is activated (screen dims) 150 seconds after no activity on the Room Controller. Adjustable: 0 to 100%.
Night backlight Default value: 5%	Night Backlight Sets backlight display intensity. Parameter only available for models with motion/ light detectors. The screen backlight progressively decreases down to this setting when room is dark. This feature is used mostly in hospitality applications when a darker non obtrusive lighting level is desired when room is dark. Adjustable: 0 to 100%.

Configuration Parameters Default Value	Significance and Adjustments
RH display Default value: Disabled	Relative Humidity Shows humidity level in room in %RH. Enabled: Display %RH Disabled: Do not display %RH Choices: Enabled or Disabled
CO2 display Default value: Disabled	CO2 Levels Display Shows carbon dioxide level in room in ppm. Enabled: Display CO2 level Disabled: Do not display CO2 level Note: The CO2 value will only be displayed on the Room Controller home screen if an optional CO2 detection sensor module is installed or a ZigBee wireless CO2 device is paired, and if there is a valid value. Choices: Enabled or Disabled

Service View Screens

The service view screens show the current status of certain points locally on the Room Controller. These points can also be viewed through the network. Service view values are **Read Only** values but allow a service contractor to visualize the status of key functionality to correctly diagnose operational system issues.

SERVICE VIEW 1/9



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Room temp. Read Only	Room Temperature Shows the current room temperature from the configured temperature source.
UI19 changover Read Only	Changeover Temperature Sensor Shows the temperature of the changeover sensor connected to UI19 terminal.
UI20 temp. Read Only	Room Temperature Sensor Shows the temperature of the sensor connected to UI20 (RS) terminal.
Outdoor temp. Read Only	Outdoor Temperature Shows the outdoor temperature on the main screen.
Room humidity Read Only	Room Humidity Shows the current room humidity percentage from the configured humidity source.

SERVICE VIEW 2/9

2/9 Service View


Effective occ.	Occupied
PI cool demand	0%
PI heat demand	0%
Cool dem. limit	0.0%
Heat dem. limit	0.0%
Supply temp.	xx.x °C

↶
↷
🏠
▼
▲

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Effective occ. Read Only	Effective Occupancy Shows as occupied, unoccupied, standby or override. Display Readings: Occupied, Unoccupied, Override and Standby
PI cool demand Read Only	Proportional Integral Cooling Demand Display Readings: 0-100%
PI heat demand Read Only	Proportional Integral Heat Demand Display Readings: 0-100%
Cool dem. limit Read Only	Cooling Demand Limit Display Readings: 0-100%
Heat dem. limit Read Only	Heat Demand Limit Display Readings: 0-100%
Supply temp. Read Only	Supply Temperature Shows supply air temperature as measured by the sensor.

SERVICE VIEW 3/9



* Only for models with onboard ZigBee or optional ZigBee add-on module.

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
UI16 binary Read Only	Universal Input Configuration No. 1 Shows status of input. Display Readings: Activated or Not Activated
UI17 binary Read Only	Universal Input Configuration No. 2 Shows status of input. Display Readings: Activated or Not Activated
UI19 binary Read Only	Universal Input Configuration No. 3 Shows status of input. Display Readings: Activated or Not Activated
Zigb. PIR inst. Read Only	ZigBee Passive Infrared Sensor Installed Shows if ZigBee wireless motion sensor is paired to a Room Controller or not. NOTE: This parameter is for ZigBee wireless motion sensors only. Display Readings: Off or On
Zigb. sens. mot. Read Only	ZigBee Sensor Motion Shows if motion is detected by any of the ZigBee wireless motion sensors. NOTE: This parameter is for ZigBee wireless motion sensors only. Display Readings: Motion or No Motion


SERVICE VIEW 4/9



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Window alarm Read Only	Window Alarm Shows On if there is a Window alarm and shows Off if there is no Window alarm. This feature is for both wired and wireless sensors. Display Readings: On or Off
Service alarm Read Only	Service Alarm Shows On if there is a Service alarm and shows Off if there is no Service alarm. Display Readings: On or Off
Filter alarm Read Only	Filter Alarm Shows On if there is a Filter alarm and shows Off if there is no Filter alarm. Display Readings: On or Off
Recovery Read Only	Recovery Status Shows if Smart Recovery is active or not. Display Readings: On or Off
Local motion Read Only	Local Motion Shows if Motion alarm is active or not. Display Readings: Motion or No Motion
Deh. status Read Only	Dehumidification Status Shows if dehumidification is active or not. Display Readings: On or Off

SERVICE VIEW 5/9



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
UO9 config Read Only	UO9 Configuration Display Readings: Analog, Binary, Relay RC or Relay RH
UO10 config Read Only	UO10 Configuration Display Readings: Analog, Binary or Relay RC
UO11 config Read Only	UO11 Configuration Display Readings: Analog or Binary
UO12 config Read Only	UO12 Configuration Display Readings: Analog or Binary
Term. 24 10V Read Only	UI24 Analog Shows the analog value of the UI24 generic Universal Input (in Volts).

SERVICE VIEW 6/9

6/9 Service View

UI19 type

Therm.

UI20 type

Therm.

UI22 type

Therm.

UI23 type

Binary

UI24 type

Voltage











PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
UI19 type Read Only	UI19 Input Type Display Readings: Thermistor, Binary or Voltage
UI20 type Read Only	UI20 Input Type Display Readings: Thermistor, Binary or Voltage
UI22 type Read Only	UI22 Input Type Display Readings: Thermistor, Binary or Voltage
UI23 type Read Only	UI23 Input Type Display Readings: Thermistor, Binary or Voltage
UI24 type Read Only	UI24 Input Type Display Readings: Thermistor, Binary, Voltage or Reserved

SERVICE VIEW 7/9

7/9 Service View

CO2 eff. source

None

CO2 err. code

0x0000

CO2 level

0 PPM


CO2 FW rev.

CO2 S/N

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
CO2 eff. source Read Only	CO2 Effective Source Shows the configured source of the indoor CO2. Display Readings: None, Local or WL 1 to WL 20
CO2 err. code Default value: 0 Read Only	CO2 Error Code Error code 0x0001 shows if there is an error with the sensor.
CO2 level Read Only	CO2 Level Shows CO2 level in PPM. Display Readings: 0 to 5000 PPM
CO2 FW rev. Read Only	CO2 Firmware Revision Shows the Firmware version of the installed CO2 sensor module.
CO2 S/N Read Only	CO2 Serial Number Shows the serial number of the installed CO2 sensor module.

SERVICE VIEW 8/9



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Eff. sys. mode Read Only	Effective System Mode Shows the current operating mode of the system. For example, when the system is in Auto mode, this parameter shows whether it is currently heating or cooling. Display Readings: Cool or Heat
Eff. setpoint Read Only	Effective Temperature Setpoint Shows the temperature setpoint value currently in use by the system.

SERVICE VIEW 9/9

9/9 Service View

Device Name:
SE8350U5BxxP-254

Firmware Revision
2.4.0

Graphic Library Revision:
4.1.0

Zigbee revision:
25.0.0

The Device Name (BACnet name) consists of the model number followed by the COM address (MAC address). The BACnet name can be changed via the BACnet front end and the new name appears on the above screen.

For example, when a SE8350U5B00 Room Controller with a MAC address of 41 is connected to a network, its default Device Name is SE8350U5B00-41 and its default BACnet Device ID is 83041.

Firmware Revision shows the Firmware version currently installed on the Room Controller. Upgrading to a newer Firmware version deletes the previous Firmware version, however it is possible to set the Room Controller to an earlier Firmware version with the Uploader Tool.

ZigBee Revision shows the Firmware version of an onboard ZigBee or optional ZigBee add-on module.

Test Outputs Screens

TEST OUTPUTS

1/2 Test Outputs

BO4 fan high

Off

BO3 fan med

Off

BO2 fan low

Off

BO8 aux. out

Off

BO1 output

Off

2/2 Test Outputs

UO9 binary

Off

UO10 binary

Off

UO11 binary

Off

UO12 binary

Off

Binary UO

1/2 Test Outputs

BO4 fan high

Off

BO3 fan med

Off

BO2 fan low

Off

BO8 aux. out

Off

BO1 output

Off

UO10 analog

0.0 Vdc

2/2 Test Outputs

UO11 analog

0.0 Vdc

UO12 analog

0.0 Vdc

Analog UO

NOTICE

SAFE OPERATION ENVIRONMENT

Use high caution when manually enabling outputs so as to not cause damage to equipment. It is the responsibility of the Installer or Service Contractor to maintain a safe operation environment during usage.

Failure to follow these instructions can result in equipment damage.

- Note 1:** The Test Outputs screen allows manual override of specified outputs. After any output state is overridden, the command is cancelled after 1 minute of screen inactivity (auto exit to main screen) or when page is exited.
- Note 2:** These parameters can also be changed via BACnet and the changed parameter background will turn red to indicate the parameter's value had been overridden. The overridden value remains even if the user exits the main screen
- Note 3:** Test Outputs values are LIVE. Any output gets displayed immediately for any value change according to the following:
1. If any BACnet priority array (1 - 16) includes a value, the displayed state background shows in red.
 2. When toggling a value on the screen, the output directly energizes according to the selected value.
 3. After any output state gets modified, all overrides get cancelled after 1 minute of button inactivity, or if you scroll from one screen to another screen.
- Note 4:** Test Outputs UO9 to UO12 are dependent on control type configuration. If mode is set to Floating or On/Off, binary options show. If mode is set to Analog, analog options show.

Language Selection Screens

LANGUAGE SELECTION




Only English, French, Spanish, Chinese, and Russian are enabled by default and are accessible to users cycling through languages on the display settings menu screen. To change the language selection settings, tap a language on the screen and then use the arrow buttons to disable or enable it.

NOTE: English is always enabled.

Clock - Schedule Screens


SCHEDULE MENU



Note: The Clock - Schedule Menu screen is directly accessible from the main setup screen.

CLOCK

The Clock settings screen allows the device's internal time settings to be changed (current time, day, month, year and weekday options), as well as to choose between a 12 hour AM / PM display or 24 hour display.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Time format Default value: AM-PM	Time Format Current time display format. Choice between 12 hour (AM - PM) time format or 24 hour time format. Note: Changing the value of this parameter automatically changes the format of the displayed value of the time parameter. Choices: AM-PM or 24 Hours
Time Default value: current time at power up	Time Standard time display, 12 hour AM-PM or 24 hour format determined by the Time Format parameter value.
Year Default value: 2019	Year Current year Range: 2000 - 2100
Month Default value: Jan.	Month Current month Range: Jan. - Dec.
Day Default value: 1	Date Current date Range: 1 - 31
Weekday Default value: Monday Read Only	Current Day Automatically set based on data received from Year/Month parameters. Range: Monday - Sunday
Time source Default value: Local Read Only	Time Source Shows the source that most recently set the time on the Room Controller. Display Readings: None, Local, BACnet, NTP or Cloud

SCHEDULE

There are seven different schedule setting screens, one for each day of the week. Each day can have different scheduled events where the Room Controller is set to Occupied status or back to Unoccupied status. The Room Controller can use the appropriate setpoints (back and forth) up to three times per day.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Occupied 1 - 3 Default value: None	Occupied 1 - 3 Defines a time when the Room Controller is automatically set to use the Occupied setpoint. Note: There are 3 separate Occupied parameter entries Range: 00:00 - 23:59
Unoccupied 1 - 3 Default value: None	Unoccupied 1 - 3 Defines a time when the Room Controller is automatically set to use the Unoccupied setpoint. Note: There are 3 separate Occupied parameter entries Range: 00:00 - 23:59

OPTIONS

The options settings allow the Room Controller to function in Occupied or Unoccupied mode following a defined Schedule type set by the user.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Occupancy cmd Default value: Occupied	Occupancy Command Loc occ: occupancy is determined by local sequences (either PIR or schedule, as configured under Occ. source). Occupied: force occupied mode. Unocc: force unoccupied mode. Choices: Loc occ, Occupied or Unocc.
Schedule type Default value: 7 days	Schedule Type 7 days: Independent scheduling identified by day of the week (Sunday - Saturday) 5+1+1 days: Weekdays scheduling and Independent Weekend scheduling identified as Weekdays, Saturday and Sunday 5+2 days: Weekdays scheduling and Weekend scheduling identified as Weekdays and Weekend Choices: 7 days, 5+2 days or 5+1+1 day

Automatic Demand Response (ADR) Screen

Automatic Demand Response (ADR) feature is used to reduce energy load when electric grid contingencies threaten supply-demand balance.

PARAMETER DETAILS


Configuration Parameters Default Value	Significance and Adjustments
Permission Default value: Off	Automatic Demand Response Permission Used to permit the ADR to be applicable or not to change the Room Controller setpoints setting or not. Off: The Load Shedding Demand will not be permitted. On: The Load Shedding Demand will be permitted. Choices: On or Off
Shed status Default value: Off Read Only	Load Shedding Status Displays the status of the Load Shedding Demand, whether it is active (On) or not (Off). The Load Shedding status is On when the Permission is On, Shed demand is On, and the Shed Override is Off. Off: Load Shedding Demand is not activated. On: Load Shedding Demand is activated. Display Readings: On or Off
Shed demand Default value: Off Read Only	Load Shedding Demand Sets the request to initiate Load Shedding. This demand can only be set through BACnet by the local Utility company. Off: No Load Shedding Demand is received or the Shedding demand is disabled. On: Received the Load Shedding Demand or received the signal to activate Load shedding. Display Readings: On or Off

Configuration Parameters Default Value	Significance and Adjustments
Shed offset Default value: 4°F (2°C)	Load Shedding Offset Used to change the effective setpoints in occupied, standby and unoccupied modes. For example, when “Shed status” is On and Room Controller is in occupied mode: The cooling setpoint is calculated as follows: Occupied cooling setpoint = occupied cooling setpoint + Load shedding offset. The heating setpoint is calculated as follows: Occupied heating setpoint = occupied heating setpoint - Load shedding offset. Choices: 4°F to 10°F (2°C to 5.5°C)
Shed override Default value: Off Read Only	Load Shedding Override Displays whether the user disabled the ADR request by the utility company. When the demand shed is applied, the user can override the ADR settings from its original setpoints settings. On: Rejects or cancels shed load demand request from utility company (setpoints remain the same). Off: Allows shed load demand request from utility company (setpoint will change according to shed offset) Display Readings: On or Off

Wireless Screens


WIRELESS MENU

The Wireless screen shows only in models with onboard ZigBee or optional ZigBee add-on module.



ECOSYSTEM SETTINGS

The Ecosystem Settings screens show the network status, the number of paired devices as well as information for each paired device. A maximum of 20 ZigBee wireless devices can be paired to each Room Controller. Tap the forward arrow to obtain information on each paired ZigBee device.



PARAMETER DETAILS


Configuration Parameters Default Value	Significance and Adjustments
Network status Default value: Not det. Read Only	ZigBee Network Status Shows current status of ZigBee network. Pwr on: ZigBee module detected but not configured No NWK: ZigBee configured but no network joined Joined: ZigBee network joined Online: Communicating Display Readings: Pwr on, No NWK, Joined and Online
Permit join Default value: Off	Permit Join Setting to 'On' allows the Room Controller to pair with a ZigBee device. Value must be set to 'On' to pair with initial device and then set to 'Off' if user wants to prevent additional ZigBee devices from joining the network. Changing this value to "Off" on the Coordinator prevents any new ZigBee devices from joining the network. Permit join can be On/Off when the Room Controller is a coordinator, however the parameter is read only when the Room Controller is a router. Permit join stays On for 3 hours. On: Allows Room Controller to pair with ZigBee wireless device Off: Prevents Room Controller from pairing with ZigBee wireless device, or prevent any additional ZigBee devices from joining network. Choices: On or Off

Configuration Parameters Default Value	Significance and Adjustments
Permit timeout Default value: 0 Read Only	Permit Join Timeout Allows ZigBee devices to join the Coordinator Room Controller for 180 minutes from the moment it is set to ON. Once the timer elapses, no devices will be able to join the network. NOTE: Permit Join parameter must be set to 'On' to enable this feature. Range: 0 or 180 minutes
Paired devices Default value: 0 Read Only	Paired ZigBee Devices Shows the number of ZigBee wireless devices currently paired with the Room Controller. A maximum of 20 ZigBee wireless devices can be paired with each Room Controller. Display Readings: 0 to 20 devices

DEVICE 1-20

This screen is a subset of the Ecosystems screen and shows data for each paired ZigBee device. The Status, Temperature, Humidity and CO2 values will only be visible if they are supported by the device.

NOTE: Device X pages will only show up once devices have been paired.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Function Default value: None	ZigBee Wireless Device Function Shows status of installed ZigBee wireless device. None: No status reported to Room Controller Window: Window sensor installed Door: Door sensor installed Motion: Device set to detect motion Env. data: Temperature, Humidity, CO2 sensor installed Remove: Removes device from Device list Water: Water leak sensor installed Refrig.: Refrigerator temperature sensor installed Freezer: Freezer temperature sensor installed Choices: None, Window, Door, Motion, Env. data, Remove, Water, Refrig. and Freezer
Comm. status Default value: Offline Read Only	Communication Status Shows if device is communicating with Room Controller Not paired: Device not paired Online: Device paired and online Offline: Device paired but offline Invalid: Device was paired and Room controller detected a communication error (selected function does not match paired sensor functionality). Display Readings: Not paired, Online, Offline and Invalid
Battery Default value: None Read Only	Wireless Device Battery Shows current status of battery in wireless device. Display Readings: None, Normal or Low

Configuration Parameters Default Value	Significance and Adjustments
Addr. Read Only	Wireless Device Address Shows unique IEEE (MAC) address of ZigBee wireless device
Device values Read Only	Device Values Shows the ZigBee wireless device values. Values displayed will be different depending on type of device: • Door and Window Sensors: Closed or Open • Motion Sensor: No Motion or Motion • Water Leak Sensor: Normal or Leak • Temperature Sensor: XX.X °C • Humidity Sensor: XX %RH • CO2 Sensor: XXX PPM

DEVICE GROUPS

The Device Groups screen shows if a particular ZigBee wireless sensor is paired with the Room Controller.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Door installed Default value: No Read Only	Door Contact Installed Shows if Door sensor is installed. Display Readings: Yes or No
Win. installed Default value: No Read Only	Window Contact Installed Shows if Window sensor is installed. Display Readings: Yes or No
Water installed Default value: No Read Only	Water Leak Sensor Installed Shows if Water Leak sensor is installed. Display Readings: Yes or No

TEMPERATURE ALARMS CONFIGURATION

The Temperature Alarms Configuration screens show the values that trigger an alarm only for ZigBee wireless sensors with temperature measurement.

1/2 Temperature

Enable
Off

Hysteresis
1.0 °C

↶
↷
🏠
▼
▲

2/2 Temperature

Ambient high
30.0 °C

Ambient low
4.5 °C

Refrig. high
4.5 °C

Refrig. low
0.0 °C

Freezer high
-17.5 °C


↶
↷
🏠
▼
▲

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Enable Default value: Off	Temperature Alarm Enabled Enables wireless device to alert Room Controller if temperature value reaches defined value in a particular paired device. Choices: On or Off
Hysteresis Default value: 2.0 °F (1.0 °C)	Temperature Alarm Hysteresis Choices: 0 to 10 °F (0 to 5.5 °C)
Ambient high Default value: 86.0 °F (30.0 °C)	Temperature Alarm Ambient High Range: 75 to 122 °F (24 to 50 °C)
Ambient low Default value: 40.0 °F (4.5 °C)	Temperature Alarm Ambient Low Range: 32 to 45 °F (0 to 7 °C)
Refrig. high Default value: 40.0 °F (4.5 °C)	Temperature Alarm Refrigerator High (only present if a refrigeration sensor is installed) Range: 32 to 50 °F (0 to 10 °C)
Refrig. low Default value: 32.0 °F (0.0 °C)	Temperature Alarm Refrigerator Low (only present if a refrigeration sensor is installed) Range: 32 to 50 °F (0 to 10 °C)
Freezer high Default value: 0.0 °F (-17.5 °C)	Temperature Alarm Freezer High (only present if a freezer sensor is installed) Range: -40 to 32 °F (-40 to 0 °C)

ALARMS

The Alarms screen shows data for paired Zigbee wireless devices.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Low battery Default value: Off Read Only	Low Battery Alarm Shows if any wireless paired device has a low battery status (On) or no paired device has low battery (Off). Display Readings: On or Off
Water leak Default value: Off Read Only	Water Leak Sensor Status Shows if any water sensor paired device has detected a water leak (On) or no leak detected in any of the water sensor paired devices (Off). Display Readings: On or Off
Low temp. Default value: Off Read Only	Low Temperature Alarm Shows if any temperature sensor paired device has detected a low temperature (On) or no low temperature detected in any of the temperature sensor paired devices (Off). Display Readings: On or Off
High temp. Default value: Off Read Only	High Temperature Alarm Shows if any temperature sensor paired device has detected a high temperature (On) or no high temperature detected in any of the temperature sensor paired devices (Off). Display Readings: On or Off

LUA Screens

The LUA settings screens show information about any custom LUA script uploaded to the Room Controller. LUA scripts are not programmable on the Room Controllers. LUA scripts can be uploaded to the Room Controller via the Uploader Tool or via BACnet.




PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Program cmd Default value: Run	Program Command Run: LUA script activated and runs continuously until deactivated Stop: LUA script deactivated Choices: Stop or Run
Program status Default value: Idle Read Only	Program Status Running: LUA script active Halted: LUA script stopped and not active Idle: LUA script is running but not currently performing any actions Waiting: LUA script running and waiting for a response Uploading: LUA script currently unloading from Room Controller Loading: LUA script currently loading to Room Controller Display Readings: Idle, Loading, Running, Waiting, Halted, Unloading
Program error Default value: No error Read Only	Program Error No error: No errors in LUA script Syntax: Syntax error in LUA script detected Runtime: Runtime error occurred while running LUA script Memory: Device has run out of memory for the script Display Readings No error, Syntax, Runtime, Memory

LUA GENERIC PARAMETERS

The LUA settings include twelve generic parameters that do not have a specific function or pre-configured functions. These parameters can be used in custom Lua scripts to store a value. They are also user configurable in their default state, but when assigned a value via a Lua script or via BACnet (Priority 1-16), they become read only (not configurable locally by the user) and the display color of the parameter changes to red. These parameters can also be configured via ZigBee, however they can still be modified locally by the user.



PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Parameter A Default value: 0	AV25 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter B Default value: 0	AV26 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter C Default value: 0	AV27 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter D Default value: 0	AV28 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter E Default value: 0	AV29 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter F Default value: 0	AV30 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter G Default value: 0	AV225 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter H Default value: 0	AV226 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter I Default value: 0	AV227 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter J Default value: 0	AV228 The value of this parameter depends on what is assigned to it from a BAS or LUA script.

PARAMETER DETAILS

Configuration Parameters Default Value	Significance and Adjustments
Parameter K Default value: 0	AV229 The value of this parameter depends on what is assigned to it from a BAS or LUA script.
Parameter L Default value: 0	AV230 The value of this parameter depends on what is assigned to it from a BAS or LUA script.

SECTION 4

Appendix A: Terminal Correspondence

The terminals of a SE8350 are identified differently and have a wider range of possible functions compared to those of any of the SE7300 series Room Controllers. Nonetheless, there is a direct correspondence of functions between the terminals of the SE7300 series and the SE8350 series. Consult the table below to verify the appropriate terminal when replacing a SE7300 Room Controller with a SE8350 Room Controller.

SE7300		SE8350	
Terminal name	Terminal ID	Terminal name	Terminal ID
Binary Input 1	BI1	Universal Input 16	UI16
Binary Input 2	BI2	Universal Input 17	UI17
Universal Input 3	UI3	Universal Input 19	UI19
Sensor Common	Scom	Terminal 18 Common	COM
Remote Sensor	RS	Universal Input 20	UI20 - RS
Sensor Common	Scom	Terminal 21 Common	COM
Mix/Supply Sensor	MS	Universal Input 22	UI22 - SS

Technical Support



For any issues with SmartStruxure Solution or SmartStruxure Lite, contact Schneider Electric Technical Support according to your region.

North America (NAM) Product Support
Building Management Systems (BMS): www.nampss.com

Global Product Support
Building Management Systems (BMS): productsupport.BMS@schneider-electric.com

Schneider Electric
CS 30323
F-92506 Rueil-Malmaison Cedex
France

Schneider Electric is leading the Digital Transformation of Energy Management and Automation in Homes, Buildings, Data Centers, Infrastructure and Industries.

With global presence in over 100 countries, Schneider is the undisputable leader in Power Management – Medium Voltage, Low Voltage and Secure Power, and in Automation Systems. We provide integrated efficiency solutions, combining energy, automation and software.

In our global Ecosystem, we collaborate with the largest Partner, Integrator and Developer Community on our Open Platform to deliver real-time control and operational efficiency.

We believe that great people and partners make Schneider a great company and that our commitment to Innovation, Diversity and Sustainability ensures that Life Is On everywhere, for everyone and at every moment.

www.schneider-electric.com