

LM-SW**Pakiet: czujnik (prędkość wiatru)**

Nr art. 22154286

For a detailed description of the product, see operating manual (link at the top). For further information, refer to data sheet LM-4WZS.

Wskazówki dotyczące planowania

- Voltage is supplied as standard via the LM-SB basic package.
- Integration into LUXMATE is via the LM-4WZS.

