



Taśma z wypustkami

Tape for fixation of the cover. For continuous lightlines it has to be positioned in the middle part on both sides as well as in the corner of configurations with corner elements (2 pieces à 30 cm)



ZS_SLI_F_tape.jpg