


Opis produktu

2025 U

Card switch insert 1-pole push switch 1 NO



Ogólne informacje

Typ produktu	2025 U
Kod zamówieniowy	2CKA001012A1713
Numer EAN	4011395656808
Opis katalogowy	Card switch insert 1-pole push switch 1 NO
Opis	Illuminable. With N terminal.

Installation

Instrukcje i podręczniki	No document needed
--------------------------	--------------------

Dane techniczne

Arkusz danych, informacja techniczna	No document needed
Napięcie znamionowe (U_n)	250 V
Prąd znamionowy (I_n)	10 A
Konfiguracja styków	1 NO, 0 NC

Liczba biegunów	1
Ilość styków normalnie otwartych	1
Design Range	63x63 Busch-art linear future linear Busch-axcent Busch-axcent pur solo carat future Busch-Dynasty Pure Stainless Steel
Konfiguracja okablowania	1-pole push switch
Typ dźwigni	Hotel card
Typ montażu	Flush Mounted
Rodzaj mocowania	Mounting with Claw Mounting with Screw
Wykończenie pokrywy	Untreated
Zapewnione miejsce na etykiety	No
Podświetlenie	Illuminated
Rodzaj pomiaru	Single push button
Funkcja aplikacji	Electrical Load and Light Control Hospitality

Normy środowiskowe

Stopień ochrony	IP20
Status RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Dane RoHS	2CKA200000E0119
Deklaracja REACH	2CKA309999E9999
Szablon raportowania CMRT	9AKK108468A3363

Wymiary

Szerokość netto	71 mm
Wysokość netto	71 mm
Głębokość / długość netto	40.1 mm
Masa netto	56 g
Głębokość zabudowy (t ₂)	32 mm

Charakterystyka zamówienia

ID produktu zastąpionego	1012-0-1713
--------------------------	-------------

Certyfikaty i deklaracje (Numer dokumentu)

Wszelkie prawa zastrzeżone

2024/01/09

Zastrzega się możliwość zmian bez powiadomienia

Deklaracja zgodności UE

2CKA100000E0022

Klasyfikacje

ETIM 8	EC000029 - Push-switch button
ETIM 9	EC000029 - Push button
Kategoria WEEE	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer
CN8	8536 50 80
eClass	V11.0 : 27144044

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001710A3294	Cover plate with legend Card for Switch/push button, Hotel card Hotel card bronze - alpha	1792-21-101	1	sztuka
2CKA001710A3297	Cover plate with legend Card for Switch/push button, Hotel card Hotel card studio white - alpha	1792-24G-101	1	sztuka
2CKA001710A3305	Cover plate with legend Card for Switch/push button, Hotel card Hotel card palladium - alpha	1792-260-101	1	sztuka
2CKA001710A3331	Cover plate with legend Card for Switch/push button, Hotel card Hotel card titanium - alpha	1792-266-101	1	sztuka
2CKA001753A0079	Cover plate with legend Card for Switch/push button, Hotel card Hotel card ivory - impuls	1792-72	1	sztuka
2CKA001753A6703	Cover plate with legend Card for Switch/push button, Hotel card Hotel card alpine white - impuls	1792-74	1	sztuka
2CKA001753A0190	Cover plate with legend Card for Switch/push button, Hotel card Hotel card studio white matt - impuls	1792-774	1	sztuka
2CKA001753A0159	Cover plate with legend Card for Switch/push button, Hotel card Hotel card black matt - impuls	1792-775	1	sztuka
2CKA001753A0080	Cover plate with legend Card for Switch/push button, Hotel card Hotel card aluminium silver - impuls	1792-783	1	sztuka
2CKA001753A6737	Cover plate with legend Card for Switch/push button, Hotel card Hotel card champagne metallic - impuls	1792-79	1	sztuka
2CKA001710A4124	Cover plate with legend Card for Switch/push button, Hotel card Hotel card grey metallic - 63x63	1792-803	1	sztuka
2CKA001710A3639	Cover plate with legend Card for Switch/push button, Hotel card Hotel card anthracite - 63x63	1792-81	1	sztuka
2CKA001710A3640	Cover plate with legend Card for Switch/push button, Hotel card Hotel card ivory white - 63x63	1792-82	1	sztuka
2CKA001710A3670	Cover plate with legend Card for Switch/push button, Hotel card Hotel card aluminium silver - 63x63	1792-83	1	sztuka
2CKA001710A3757	Cover plate with legend Card for Switch/push button, Hotel card Hotel card stainless steel - Pure Stainless Steel	1792-866	1	sztuka

2CKA001710A3928	Cover plate with legend Card for Switch/push button, Hotel card Hotel card studio white matt - 63x63	1792-884	1	sztuka
2CKA001710A3905	Cover plate with legend Card for Switch/push button, Hotel card Hotel card black matt - 63x63	1792-885	1	sztuka
2CKA001710A3865	Mechanical Controls Card for Switch/push button, Hotel card Hotel card white - Basic55	1792-92-507	1	sztuka
2CKA001710A3929	Mechanical Controls Card for Switch/push button, Hotel card Hotel card champagne - Basic55	1792-93-507	1	sztuka
2CKA001710A3864	Mechanical Controls Card for Switch/push button, Hotel card Hotel card alpine white - Basic55	1792-94-507	1	sztuka
2CKA001710A3933	Mechanical Controls Card for Switch/push button, Hotel card Hotel card château-black - Basic55	1792-95-507	1	sztuka
2CKA001754A4516	Cover Frame 1gang white - Busch-Duro 2000	1721 NS-212-500	1	sztuka
2CKA001754A4496	Cover Frame 1gang alpine white - Reflex SI	1721 NS-214-500	1	sztuka
2CKA001754A4093	Cover Frame 1gang white - Busch-Duro 2000 SI Linear	1721 NSKA-212	1	sztuka
2CKA001754A4497	Cover Frame 1gang alpine white - Reflex SI Linear	1721 NSKA-214-500	1	sztuka
2CKA001754A4521	Cover Frame 1gang platinum - alpha nea	1721-20-500	1	sztuka
2CKA001754A4522	Cover Frame 1gang bronze - alpha nea	1721-21-500	1	sztuka
2CKA001754A4775	Cover Frame 1gang glass purple - Busch-axcent pur	1721-223	1	sztuka
2CKA001754A4760	Cover Frame 1gang glass sun - Busch-axcent pur	1721-225	1	sztuka
2CKA001754A4770	Cover Frame 1gang glass avocado - Busch-axcent pur	1721-226	1	sztuka
2CKA001754A4765	Cover Frame 1gang glass coral - Busch-axcent pur	1721-227	1	sztuka
2CKA001754A4755	Cover Frame 1gang glass ocean - Busch-axcent pur	1721-228	1	sztuka
2CKA001754A4780	Cover Frame 1gang glass oyster - Busch-axcent pur	1721-229	1	sztuka
2CKA001754A4512	Cover Frame 1gang ivory - alpha nea	1721-22G-500	1	sztuka
2CKA001754A4790	Cover Frame 1gang paper brown - Busch-axcent pur	1721-243	1	sztuka
2CKA001754A4800	Cover Frame 1gang glass black - Busch-axcent pur	1721-245	1	sztuka
2CKA001754A4785	Cover Frame 1gang paper blue - Busch-axcent pur	1721-248	1	sztuka
2CKA001754A4503	Cover Frame 1gang studio white - alpha nea	1721-24G-500	1	sztuka
2CKA001754A4688	Cover Frame 1gang platinum - Busch-axcent pur	1721-270-500	1	sztuka
2CKA001754A4708	Cover Frame 1gang black matt - Busch-axcent pur	1721-275-500	1	sztuka
2CKA001754A4698	Cover Frame 1gang titanium - Busch-axcent pur	1721-276-500	1	sztuka
2CKA001754A4437	Cover Frame 1gang white glass - Busch-axcent pur	1721-280	1	sztuka
2CKA001754A4409	Cover Frame 1gang black - Busch-axcent	1721-281	1	sztuka
2CKA001754A4331	Cover Frame 1gang studio white - Busch-axcent	1721-284	1	sztuka
2CKA001754A4334	Cover Frame 1gang yellow - Busch-axcent	1721-285	1	sztuka
2CKA001754A4337	Cover Frame 1gang green - Busch-axcent	1721-286	1	sztuka

2CKA001754A4340	Cover Frame 1gang red - Busch-axcent	1721-287	1	sztuka
2CKA001754A4343	Cover Frame 1gang blue - Busch-axcent	1721-288	1	sztuka
2CKA001754A4805	Cover Frame 1gang slate grey - Busch-axcent pur	1721-290	1	sztuka
2CKA001754A4471	Cover Frame 1gang entrée grey - Busch-axcent	1721-291-500	1	sztuka
2CKA001754A4795	Cover Frame 1gang concrete grey - Busch-axcent pur	1721-298	1	sztuka
2CKA001754A4505	Cover Frame 1gang ivory - impuls	1721-72-500	1	sztuka
2CKA001754A4514	Cover Frame 1gang chrome - impuls	1721-726-500	1	sztuka
2CKA001754A4507	Cover Frame 1gang solar gold - impuls	1721-73-500	1	sztuka
2CKA001754A4513	Cover Frame 1gang alpine white - impuls	1721-74-500	1	sztuka
2CKA001754A4222	Cover Frame 1gang alpine white - impuls	1721-74-507	1	sztuka
2CKA001754A4429	Cover Frame 1gang studio white matt - impuls	1721-774	1	sztuka
2CKA001754A4430	Cover Frame 1gang studio white matt - impuls	1721-774-507	1	sztuka
2CKA001754A4424	Cover Frame 1gang black matt - impuls	1721-775	1	sztuka
2CKA001754A4510	Cover Frame 1gang champagne metallic - impuls	1721-79-500	1	sztuka
2CKA001754A4225	Cover Frame 1gang champagne metallic - impuls	1721-79-507	1	sztuka
2CKA001754A4535	Cover Frame 1gang chrome - solo	1721-80-500	1	sztuka
2CKA001754A4538	Cover Frame 1gang chrome gloss - solo	1721-80G-500	1	sztuka
2CKA001754A4442	Cover Frame 1gang white glass - carat	1721-811	1	sztuka
2CKA001754A4820	Cover Frame 1gang porcelain anthracite - carat	1721-815	1	sztuka
2CKA001754A4258	Cover Frame 1gang bronze - carat	1721-821	1	sztuka
2CKA001754A4356	Cover Frame 1gang gold - carat	1721-823-101	1	sztuka
2CKA001754A4322	Cover Frame 1gang glass black - carat	1721-825	1	sztuka
2CKA001754A4360	Cover Frame 1gang chrome - carat	1721-826-101	1	sztuka
2CKA001754A4605	Cover Frame 1gang anthracite - Busch-Dynasty	1721-831-500	1	sztuka
2CKA001754A4600	Cover Frame 1gang ivory white - Busch-Dynasty	1721-832-500	1	sztuka
2CKA001754A4575	Cover Frame 1gang polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	sztuka
2CKA001754A4565	Cover Frame 1gang polished brass anthracite - Busch-Dynasty	1721-835-500	1	sztuka
2CKA001754A4570	Cover Frame 1gang polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	sztuka
2CKA001754A4560	Cover Frame 1gang polished brass ivory white - Busch-Dynasty	1721-838-500	1	sztuka
2CKA001754A4595	Cover Frame 1gang antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	sztuka
2CKA001754A4536	Cover Frame 1gang studio white - solo	1721-84-500	1	sztuka
2CKA001754A4585	Cover Frame 1gang antique brass anthracite - Busch-Dynasty	1721-845-500	1	sztuka
2CKA001754A4590	Cover Frame 1gang antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	sztuka
2CKA001754A4580	Cover Frame 1gang antique brass ivory white - Busch-Dynasty	1721-848-500	1	sztuka
2CKA001754A4254	Cover Frame 1gang stainless steel - carat	1721-860	1	sztuka
2CKA001754A2239	Cover Frame 2gang white - Busch-Duro 2000	1722 NS-212	1	sztuka
2CKA001754A2163	Cover Frame 2gang alpine white - Reflex SI	1722 NS-214	1	sztuka
2CKA001754A4094	Cover Frame 2gang white - Busch-Duro 2000 SI Linear	1722 NSKA-212	1	sztuka

2CKA001754A4059	Cover Frame 2gang alpine white - Reflex SI Linear	1722 NSKA-214	1	sztuka
2CKA001754A4524	Cover Frame 2gang platinum - alpha nea	1722-20-500	1	sztuka
2CKA001754A1710	Cover Frame 2gang bronze - alpha nea	1722-21	1	sztuka
2CKA001754A4776	Cover Frame 2gang glass purple - Busch-axcent pur	1722-223	1	sztuka
2CKA001754A4761	Cover Frame 2gang glass sun - Busch-axcent pur	1722-225	1	sztuka
2CKA001754A4771	Cover Frame 2gang glass avocado - Busch-axcent pur	1722-226	1	sztuka
2CKA001754A4766	Cover Frame 2gang glass coral - Busch-axcent pur	1722-227	1	sztuka
2CKA001754A4756	Cover Frame 2gang glass ocean - Busch-axcent pur	1722-228	1	sztuka
2CKA001754A4781	Cover Frame 2gang glass oyster - Busch-axcent pur	1722-229	1	sztuka
2CKA001754A3799	Cover Frame 2gang ivory - alpha nea	1722-22G	1	sztuka
2CKA001754A4791	Cover Frame 2gang paper brown - Busch-axcent pur	1722-243	1	sztuka
2CKA001754A4801	Cover Frame 2gang glass black - Busch-axcent pur	1722-245	1	sztuka
2CKA001754A4786	Cover Frame 2gang paper blue - Busch-axcent pur	1722-248	1	sztuka
2CKA001754A4511	Cover Frame 2gang studio white - alpha nea	1722-24G-500	1	sztuka
2CKA001754A4689	Cover Frame 2gang platinum - Busch-axcent pur	1722-270-500	1	sztuka
2CKA001754A4709	Cover Frame 2gang black matt - Busch-axcent pur	1722-275-500	1	sztuka
2CKA001754A4699	Cover Frame 2gang titanium - Busch-axcent pur	1722-276-500	1	sztuka
2CKA001754A4438	Cover Frame 2gang white glass - Busch-axcent pur	1722-280	1	sztuka
2CKA001754A4410	Cover Frame 2gang black - Busch-axcent	1722-281	1	sztuka
2CKA001754A4332	Cover Frame 2gang studio white - Busch-axcent	1722-284	1	sztuka
2CKA001754A4335	Cover Frame 2gang yellow - Busch-axcent	1722-285	1	sztuka
2CKA001754A4338	Cover Frame 2gang green - Busch-axcent	1722-286	1	sztuka
2CKA001754A4341	Cover Frame 2gang red - Busch-axcent	1722-287	1	sztuka
2CKA001754A4344	Cover Frame 2gang blue - Busch-axcent	1722-288	1	sztuka
2CKA001754A4806	Cover Frame 2gang slate grey - Busch-axcent pur	1722-290	1	sztuka
2CKA001754A4472	Cover Frame 2gang entrée grey - Busch-axcent	1722-291-500	1	sztuka
2CKA001754A4796	Cover Frame 2gang concrete grey - Busch-axcent pur	1722-298	1	sztuka
2CKA001754A4482	Cover Frame 2gang maison-beige - Busch-axcent	1722-299-500	1	sztuka
2CKA001754A4313	Cover Frame 2gang ivory - impuls	1722-72	1	sztuka
2CKA001754A4134	Cover Frame 2gang chrome - impuls	1722-726	1	sztuka
2CKA001754A4525	Cover Frame 2gang alpine white - impuls	1722-74-500	1	sztuka
2CKA001754A4226	Cover Frame 2gang alpine white - impuls	1722-74-507	1	sztuka
2CKA001754A4431	Cover Frame 2gang studio white matt - impuls	1722-774	1	sztuka
2CKA001754A4432	Cover Frame 2gang studio white matt - impuls	1722-774-507	1	sztuka
2CKA001754A4425	Cover Frame 2gang black matt - impuls	1722-775	1	sztuka
2CKA001754A2528	Cover Frame 2gang champagne metallic - impuls	1722-79	1	sztuka

2CKA001754A4537	Cover Frame 2gang chrome - solo	1722-80-500	1	sztuka
2CKA001754A4327	Cover Frame 2gang chrome gloss - solo	1722-80G	1	sztuka
2CKA001754A4443	Cover Frame 2gang white glass - carat	1722-811	1	sztuka
2CKA001754A4821	Cover Frame 2gang porcelain anthracite - carat	1722-815	1	sztuka
2CKA001754A4259	Cover Frame 2gang bronze - carat	1722-821	1	sztuka
2CKA001754A4357	Cover Frame 2gang gold - carat	1722-823-101	1	sztuka
2CKA001754A4323	Cover Frame 2gang glass black - carat	1722-825	1	sztuka
2CKA001754A4361	Cover Frame 2gang chrome - carat	1722-826-101	1	sztuka
2CKA001754A4606	Cover Frame 2gang anthracite - Busch-Dynasty	1722-831-500	1	sztuka
2CKA001754A4601	Cover Frame 2gang ivory white - Busch-Dynasty	1722-832-500	1	sztuka
2CKA001754A4576	Cover Frame 2gang polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	sztuka
2CKA001754A4566	Cover Frame 2gang polished brass anthracite - Busch-Dynasty	1722-835-500	1	sztuka
2CKA001754A4571	Cover Frame 2gang polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	sztuka
2CKA001754A4561	Cover Frame 2gang polished brass ivory white - Busch-Dynasty	1722-838-500	1	sztuka
2CKA001754A4596	Cover Frame 2gang antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	sztuka
2CKA001754A4586	Cover Frame 2gang antique brass anthracite - Busch-Dynasty	1722-845-500	1	sztuka
2CKA001754A4591	Cover Frame 2gang antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	sztuka
2CKA001754A4581	Cover Frame 2gang antique brass ivory white - Busch-Dynasty	1722-848-500	1	sztuka
2CKA001754A4255	Cover Frame 2gang stainless steel - carat	1722-860	1	sztuka
2CKA001754A3708	Cover Frame 3gang white - Busch-Duro 2000	1723 NS-212	1	sztuka
2CKA001754A3724	Cover Frame 3gang alpine white - Reflex SI	1723 NS-214	1	sztuka
2CKA001754A4096	Cover Frame 3gang white - Busch-Duro 2000 SI Linear	1723 NSKA-212	1	sztuka
2CKA001754A4061	Cover Frame 3gang alpine white - Reflex SI Linear	1723 NSKA-214	1	sztuka
2CKA001754A1637	Cover Frame 3gang platinum - alpha nea	1723-20	1	sztuka
2CKA001754A1728	Cover Frame 3gang bronze - alpha nea	1723-21	1	sztuka
2CKA001754A4777	Cover Frame 3gang glass purple - Busch-axcent pur	1723-223	1	sztuka
2CKA001754A4762	Cover Frame 3gang glass sun - Busch-axcent pur	1723-225	1	sztuka
2CKA001754A4772	Cover Frame 3gang glass avocado - Busch-axcent pur	1723-226	1	sztuka
2CKA001754A4767	Cover Frame 3gang glass coral - Busch-axcent pur	1723-227	1	sztuka
2CKA001754A4757	Cover Frame 3gang glass ocean - Busch-axcent pur	1723-228	1	sztuka
2CKA001754A3807	Cover Frame 3gang ivory - alpha nea	1723-22G	1	sztuka
2CKA001754A4792	Cover Frame 3gang paper brown - Busch-axcent pur	1723-243	1	sztuka
2CKA001754A4802	Cover Frame 3gang glass black - Busch-axcent pur	1723-245	1	sztuka

2CKA001754A4787	Cover Frame 3gang paper blue - Busch-axcent pur	1723-248	1	sztuka
2CKA001754A4518	Cover Frame 3gang studio white - alpha nea	1723-24G-500	1	sztuka
2CKA001754A4690	Cover Frame 3gang platinum - Busch-axcent pur	1723-270-500	1	sztuka
2CKA001754A4710	Cover Frame 3gang black matt - Busch-axcent pur	1723-275-500	1	sztuka
2CKA001754A4700	Cover Frame 3gang titanium - Busch-axcent pur	1723-276-500	1	sztuka
2CKA001754A4439	Cover Frame 3gang white glass - Busch-axcent pur	1723-280	1	sztuka
2CKA001754A4411	Cover Frame 3gang black - Busch-axcent	1723-281	1	sztuka
2CKA001754A4333	Cover Frame 3gang studio white - Busch-axcent	1723-284	1	sztuka
2CKA001754A4336	Cover Frame 3gang yellow - Busch-axcent	1723-285	1	sztuka
2CKA001754A4339	Cover Frame 3gang green - Busch-axcent	1723-286	1	sztuka
2CKA001754A4342	Cover Frame 3gang red - Busch-axcent	1723-287	1	sztuka
2CKA001754A4345	Cover Frame 3gang blue - Busch-axcent	1723-288	1	sztuka
2CKA001754A4807	Cover Frame 3gang slate grey - Busch-axcent pur	1723-290	1	sztuka
2CKA001754A4473	Cover Frame 3gang entrée grey - Busch-axcent	1723-291-500	1	sztuka
2CKA001754A4797	Cover Frame 3gang concrete grey - Busch-axcent pur	1723-298	1	sztuka
2CKA001754A4483	Cover Frame 3gang maison-beige - Busch-axcent	1723-299-500	1	sztuka
2CKA001754A4314	Cover Frame 3gang ivory - impuls	1723-72	1	sztuka
2CKA001754A4135	Cover Frame 3gang chrome - impuls	1723-726	1	sztuka
2CKA001754A2437	Cover Frame 3gang alpine white - impuls	1723-74	1	sztuka
2CKA001754A4433	Cover Frame 3gang studio white matt - impuls	1723-774	1	sztuka
2CKA001714A0295	Label Braille Symbol "light" - Allwetter 44 (IP 44)	2144 LI	1	sztuka
2CKA001784A0545	Illumination set Switch/push button Orange Neon lamp 230 V - Busch-Duro 2000 SM	8350	1	sztuka
2CKA001784A0560	Illumination set Switch/push button Orange Neon lamp 230 V - Busch-Duro 2000 SM	8352	1	sztuka
2CKA001784A0578	Illumination set Switch/push button Orange Neon lamp 230 V - Busch-Duro 2000 SM	8353	1	sztuka
2CKA001784A0552	Illumination set Orange Neon lamp 230 V red - Busch-Duro 2000 SM	8360	1	sztuka
2CKA001784A0586	Illumination set Switch/push button Orange Neon lamp 230 V yellow - Busch-Duro 2000 SM	8362	1	sztuka
2CKA001784A0594	Illumination set Switch/push button Orange Neon lamp 230 V white - Busch-Duro 2000 SM	8363	1	sztuka
2CKA001784A0024	Illumination set Switch/push button White Incandescent lamp 3 ... 8 V - Busch-Duro 2000 SM	8333-1	1	sztuka
2CKA001784A0032	Illumination set Switch/push button White Incandescent lamp 24 V - Busch-Duro 2000 SM	8337-1	1	sztuka
2CKA001784A0164	Illumination set Switch/push button White Incandescent lamp 8 V - Busch-Duro 2000 SM	8344-1	1	sztuka
2CKA001784A0289	Illumination set Switch/push button White Incandescent lamp 12 V - Busch-Duro 2000 SM	8345-1	1	sztuka

Kategorie

Produkty niskiego napięcia i systemy → Wiring Accessories - Light Switch Ranges → Flush Mounted Inserts → Mechanical Inserts

