

Opis produktu

1724-866K

Cover Frame 4gang stainless steel - Pure Stainless Steel



Ogólne informacje

Typ produktu	1724-866K
Kod zamówieniowy	2CKA001754A4320
Numer EAN	4011395088395
Opis katalogowy	Cover Frame 4gang stainless steel - Pure Stainless Steel
Opis	For vertical or horizontal installation. Material stainless steel. Anti fingerprint.

Installation

Instrukcje i podręczniki	No document needed
--------------------------	--------------------

Dane techniczne

Arkusz danych, informacja techniczna	No document needed
Liczba	4
Design Range	Pure Stainless Steel
Typ montażu	Flush Mounted
Rodzaj mocowania	Clamp
Orientacja montażu	Horizontal

	Vertical
Wykończenie pokrywy	Untreated Matt
Material	Stainless steel
Zapewnione miejsce na etykiety	No
Kolor	stainless steel

Normy środowiskowe

Stopień ochrony	IP20
Status RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Dane RoHS	2CKA200000E2669
Deklaracja REACH	2CKA309999E9999
Szablon raportowania CMRT	9AKK108468A3363

Wymiary

Szerokość netto	80 mm
Wysokość netto	293 mm
Głębokość / długość netto	11 mm
Masa netto	102.5 g

Charakterystyka zamówienia

ID produktu zastąpionego	1754-0-4320
--------------------------	-------------

Certyfikaty i deklaracje (Numer dokumentu)

Deklaracja zgodności UE	No Declaration needed
-------------------------	-----------------------

Klasyfikacje

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Kategoria WEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144001

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001731A1954	Rocker for Switch, Pull cord stainless steel - Pure Stainless Steel	1720-866	1	sztuka
2CKA001710A3812	Cover plate with legend Level switch Turn button stainless steel - Pure Stainless Steel	1740 DR/03-866	1	sztuka

2CKA001710A3771	Mechanical Controls Symbol "2-1-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	1740 DRL-866-503	1	sztuka
2CKA001710A3748	Cover plate with legend Symbol "arrows" for Venetian blind, Turn button stainless steel - Pure Stainless Steel	1740-866	1	sztuka
2CKA001710A3751	Cover Plate Blind cap 1 gang with Mounting plate stainless steel - Pure Stainless Steel	1742-866	1	sztuka
2CKA001724A4369	Cover Plate SAT 4 gang stainless steel - Pure Stainless Steel	1743/10-04-866	1	sztuka
2CKA001724A4378	Cover Plate SAT 4 gang stainless steel - Pure Stainless Steel	1743-04-866	1	sztuka
2CKA001724A4271	Cover Plate SAT 3 gang stainless steel - Pure Stainless Steel	1743-866	1	sztuka
2CKA001710A3766	Cover Plate telephone connector boxes (VDo) stainless steel - Pure Stainless Steel	1745-866	1	sztuka
2CKA001710A3768	Cover Plate Telecommunication inserts 50 x 50 mm stainless steel - Pure Stainless Steel	1746/10-866	1	sztuka
2CKA001710A3769	Cover Plate with Hinged Lid Telecommunication inserts 50 x 50 mm 1 gang stainless steel - Pure Stainless Steel	1746-866	1	sztuka
2CKA001710A4097	Intermediate Ring for cover plates Busch-Balance® SI stainless steel - Pure Stainless Steel	1747 BSI-866	1	sztuka
2CKA001710A3752	Cover Plate Cable outlet with Mounting plate stainless steel - Pure Stainless Steel	1749-866	1	sztuka
2CKA001723A0255	Cover Plate Loudspeaker 2 gang stainless steel - Pure Stainless Steel	1751-866	1	sztuka
2CKA001710A3749	Cover plate with legend Symbol "arrows" or "0 - 1" for Venetian blind, Key stainless steel - Pure Stainless Steel	1755 SL/PZ-866-101	1	sztuka
2CKA001724A4272	Cover plate with labelling field For data connection housing 2 gang stainless steel - Pure Stainless Steel	1758-866	1	sztuka
2CKA001731A4003	Rocker with labelling field Symbol "bell" for Switch/push button, Single push button stainless steel - Pure Stainless Steel	1764 NLI/KI-866	1	sztuka
2CKA001731A1953	Rocker with labelling field for Switch/push button, Single push button stainless steel - Pure Stainless Steel	1764 NLI-866	1	sztuka
2CKA001710A3765	Cover Plate TAE 1 gang stainless steel - Pure Stainless Steel	1766-866	1	sztuka
2CKA001753A0259	Cover Plate Symbol "1" for Time switch, Toggle stainless steel - Pure Stainless Steel	1770-866-103	1	sztuka
2CKA001753A0302	Cover Plate Symbol "0" for Time switch, Toggle stainless steel - Pure Stainless Steel	1771-866-103	1	sztuka
2CKA001751A2964	Rocker with legend Symbol "arrows" for Venetian blind, Two-part rocker stainless steel - Pure Stainless Steel	1785 JA-866	1	sztuka
2CKA001751A2996	Rocker with legend DND, MUR for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785/11-866	1	sztuka
2CKA001751A3087	Mechanical Controls Without imprint for Switch/push button, Two-part rocker stainless steel - Pure Stainless Steel	1785-866-500	1	sztuka
2CKA001751A3002	Rocker DND for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786/11-866	1	sztuka
2CKA001751A3077	Mechanical Controls Without imprint for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1786-866-500	1	sztuka
2CKA001751A2961	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1788-866	1	sztuka
2CKA001751A2963	Rocker with legend Heizung for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 H-866	1	sztuka

2CKA001751A2959	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 KI-866	1	sztuka
2CKA001751A2958	Rocker with legend Symbol "light" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 LI-866	1	sztuka
2CKA001751A3152	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 N-866	1	sztuka
2CKA001751A3162	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 ST-866	1	sztuka
2CKA001751A2960	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789 TR-866	1	sztuka
2CKA001751A2957	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	1789-866	1	sztuka
2CKA001710A3757	Cover plate with legend Card for Switch/push button, Hotel card Hotel card stainless steel - Pure Stainless Steel	1792-866	1	sztuka
2CKA001710A3761	Cover plate with legend for Thermostat Turn button stainless steel - Pure Stainless Steel	1794 TA-866	1	sztuka
2CKA001710A4018	Cover plate with legend for Thermostat Turn button stainless steel - Pure Stainless Steel	1795 HK-866	1	sztuka
2CKA001710A4050	Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 HKEA-866	1	sztuka
2CKA001710A3762	Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795 TA-866	1	sztuka
2CKA001710A3756	Cover plate with legend for Thermostat Turn button 1 sliding switch stainless steel - Pure Stainless Steel	1795-866	1	sztuka
2CKA001753A0312	Cover Plate Pull cord stainless steel - Pure Stainless Steel	1796-866	1	sztuka
2CKA001710A3767	Cover plate with labelling field Modular Jack 2 gang stainless steel - Pure Stainless Steel	1800-866	1	sztuka
2CKA001710A3764	Cover plate with labelling field UAE/IAE (ISDN) 2 gang stainless steel - Pure Stainless Steel	1803-02-866	1	sztuka
2CKA001710A3763	Cover plate with labelling field UAE/IAE (ISDN) 1 gang stainless steel - Pure Stainless Steel	1803-866	1	sztuka
2CKA002013A5408	Busch-Object socket outlet SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	20 EUAB-866	1	sztuka
2CKA002011A6212	Socket Outlets stainless steel - Pure Stainless Steel	20 EUC-866-500	1	sztuka
2CKA002013A5419	Busch-Service-Socket SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	20 EUCBDR-866	1	sztuka
2CKA002013A5289	SCHUKO® socket insert Safety Shutter withControl light; LED /Green stainless steel - Pure Stainless Steel	20 EUCBL-866	1	sztuka
2CKA002013A5460	Busch-steplight SCHUKO® socket insert Safety Shutter withNight light; LED /White stainless steel - Pure Stainless Steel	20 EUCBLI-866	1	sztuka
2CKA002013A5277	SCHUKO® Socket insert with print Safety Shutter stainless steel - Pure Stainless Steel	20 EUCKS/DV-866	1	sztuka
2CKA002013A5374	Socket Outlets Safety Shutter stainless steel - Pure Stainless Steel	20 EUCKS-866-500	1	sztuka
2CKA002013A5432	SCHUKO® Socket insert with labelling field Safety Shutter stainless steel - Pure Stainless Steel	20 EUCNB-866	1	sztuka
2CKA002013A5442	SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	20 EUCRB-866	1	sztuka
2CKA002018A1490	SCHUKO® socket insert with Hinged Lid stainless steel - Pure Stainless Steel	20 EUK-866	1	sztuka
2CKA002018A1521	SCHUKO® socket insert Safety Shutter with Hinged Lid stainless steel - Pure Stainless Steel	20 EUKB-866	1	sztuka

2CKA002011A3851	SCHUKO® Socket insert with labelling field stainless steel - Pure Stainless Steel	20 EUN-866	1	sztuka
2CKA001751A3171	Bell push-switch DND / MUR insert DND, MUR and Symbol "bell" Single push button Push button 1 pole, 1NO stainless steel - Pure Stainless Steel	2029 UC-866	1	sztuka
2CKA002495A0090	Socket insert Equipotential compensation Socket outlet 2-position stainless steel - Pure Stainless Steel	2095 UC-866	1	sztuka
2CKA002190A0217	Socket Outlets British Standard stainless steel - Pure Stainless Steel	2190 EUC-866	1	sztuka
2CKA002013A5478	SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	23 EUCB-866	1	sztuka
2CKA002013A5452	SCHUKO® socket insert Safety Shutter stainless steel - Pure Stainless Steel	2300 EUCB-866	1	sztuka
2CKA002011A3853	Busch-Protector® SCHUKO® socket insert stainless steel - Pure Stainless Steel	2310EUGL/VA-866-11	1	sztuka
2CKA002130A0293	Socket Outlets stainless steel - Pure Stainless Steel	2332 UJBS-866	1	sztuka
2CKA002099A0243	Socket Safety Shutter stainless steel - Pure Stainless Steel	2399 UCKS-866	1	sztuka
2CKA001719A0221	Intermediate Ring with Hinged Lid for cover plates Busch-Balance® SI 1 gang with Sealing Ring stainless steel - Pure Stainless Steel	2518-WD-866	1	sztuka
2CKA001751A3181	Rocker with legend Symbol "bell" for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 KI-866	1	sztuka
2CKA001751A3191	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 LI-866	1	sztuka
2CKA001751A3200	Rocker for Switch/push button, Single rocker stainless steel - Pure Stainless Steel	2520 TR-866	1	sztuka
2CKA001724A4270	Cover Plate Bore hole 1 gang stainless steel - Pure Stainless Steel	2533-866	1	sztuka
2CKA001710A3758	Cover plate with legend Symbol "0-1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	2542 DR/01-866	1	sztuka
2CKA001710A3759	Cover plate with legend Symbol "1-2-3" for Level switch, Turn button stainless steel - Pure Stainless Steel	2542 DR/02-866	1	sztuka
2CKA001724A4403	Cover Plate XLR 1 gang stainless steel - Pure Stainless Steel	2553-866	1	sztuka
2CKA001753A0395	Cover Plate Modular Jack 2 gang stainless steel - Pure Stainless Steel	2561-02-866	1	sztuka
2CKA001753A0404	Cover Plate Modular Jack 1 gang stainless steel - Pure Stainless Steel	2561-866	1	sztuka
2CKA003116A0669	FI-Schukomat SCHUKO® socket insert Protective Contact (SCHUKO) 30 mA stainless steel - Pure Stainless Steel	3120 EUCB-866	1	sztuka
2CKA003117A0011	Buschmat RCD - Insert RCD 30 mA stainless steel - Pure Stainless Steel	3151 UC-866	1	sztuka
2CKA006115A0492	6108/61-866-500 Coverplate f. CE	6108/61-866-500	1	sztuka
2CKA006155A0069	6109/03-866-500 Coverplate f. RTC	6109/03-866-500	1	sztuka
2CKA006132A0385	6122/10-866-500 BW standard	6122/10-866-500	1	sztuka
2CKA006115A0211	6125/01-866-500 Control element 1g w. BAU	6125/01-866-500	1	sztuka
2CKA006115A0223	6125/02-866-500 Control element 1/2gang	6125/02-866-500	1	sztuka
2CKA006116A0201	6126/01-866-500 Control element 2g w. BAU	6126/01-866-500	1	sztuka
2CKA006116A0213	6126/02-866-500 Control element 2/4gang	6126/02-866-500	1	sztuka

2CKA006117A0227	6127/01-866-500 Control element 4g w. BAU	6127/01-866-500	1	sztuka
2CKA006117A0239	6127/02-866-500 Control element 4/8gang	6127/02-866-500	1	sztuka
2CKA006134A0335	6128/28-866-500 RTC Control element 2/4g	6128/28-866-500	1	sztuka
2CKA006135A0162	6129/01-866-500 Control element 3/6g w. IR	6129/01-866-500	1	sztuka
2CKA006310A0106	6340-866-101-500 Control element 1-gang	6340-866-101-500	1	sztuka
2CKA006310A0114	6341-866-101-500 Rotary control element 1-gang	6341-866-101-500	1	sztuka
2CKA006310A0122	6342-866-101-500 Control element 3-gang	6342-866-101-500	1	sztuka
2CKA006310A0078	6345-866-101-500 Motion sensor	6345-866-101-500	1	sztuka
2CKA006430A0343	Control Element for Venetian blind stainless steel - Pure Stainless Steel	6430-866-102	1	sztuka
2CKA006430A0344	Cover plate with legend for Time switch Central cover plate stainless steel - Pure Stainless Steel	6435-866	1	sztuka
2CKA006470A0009	Cover Plate for Proximity switch stainless steel - Pure Stainless Steel	6476-866	1	sztuka
2CKA006400A0064	Cover Plate PowerDock 1 gang stainless steel - Pure Stainless Steel	6477-866	1	sztuka
2CKA006599A2959	Cover Plate for Dimmer Turn button with Neon lamp stainless steel - Pure Stainless Steel	6540-866-102	1	sztuka
2CKA006599A2924	Cover Plate for Cooling Central cover plate stainless steel - Pure Stainless Steel	6541-866	1	sztuka
2CKA006599A2926	Control Element for Switch/dimmer Single push button stainless steel - Pure Stainless Steel	6543-866-101	1	sztuka
2CKA006599A2927	Control Element for Dimmer Two-part button with Neon lamp stainless steel - Pure Stainless Steel	6545-866	1	sztuka
2CKA006730A0041	WaveLine Electronic Controls 1 channel Radio Control stainless steel - Pure Stainless Steel	6731-866-500	1	sztuka
2CKA006730A0042	Wall sensor 2 channel Radio Control stainless steel - Pure Stainless Steel	6732-866-500	1	sztuka
2CKA006730A0043	Electronic Controls 4 channel Radio Control stainless steel - Pure Stainless Steel	6733-866-500	1	sztuka
2CKA006730A0139	Control Element for Dimmer Two-part button stainless steel - Pure Stainless Steel	6736 FoH-866	1	sztuka
2CKA006800A2843	Electronic Controls stainless steel - Pure Stainless Steel	6815-866-101-500	1	sztuka
2CKA008200A0264	Cover plate with legend Radio 0 gang stainless steel - Pure Stainless Steel	8252-866-101-500	1	sztuka
2CKA008200A0087	Cover Plate Loudspeaker stainless steel - Pure Stainless Steel	8253-866	1	sztuka
2CKA006220A0549	CP-FCC-866 C-plate Fan Coil	CP-FCC-866	1	sztuka
2CKA006220A0546	CP-RTC-866 C-plate RT sensor unit	CP-RTC-866	1	sztuka
2CKA006220A0547	MD-F-1.0.1-866 Movement detector	MD-F-1.0.1-866	1	sztuka
2CKA006220A0548	MSA-F-1.1.1-866 Mov. detector/actuator 1g	MSA-F-1.1.1-866	1	sztuka
2CKA006200A0096	MSA-F-1.1.1-866-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-866-WL	1	sztuka
2CKA006220A0533	Electronic Controls free@home stainless steel - solo	SR-1-866	1	sztuka
2CKA006220A0538	Electronic Controls free@home stainless steel - solo	SR-2-866	1	sztuka
2CKA006220A0535	Electronic Controls free@home stainless steel - solo	SRB-1-866	1	sztuka

2CKA006220A0540	Electronic Controls free@home stainless steel - solo	SRB-2-866	1	sztuka
2CKA006220A0537	Electronic Controls free@home stainless steel - solo	SRD-1-866	1	sztuka
2CKA006220A0542	Electronic Controls free@home stainless steel - solo	SRD-2-L-866	1	sztuka
2CKA006220A0543	Electronic Controls free@home stainless steel - solo	SRD-2-R-866	1	sztuka
2CKA006220A0534	Electronic Controls free@home stainless steel - solo	SRL-1-866	1	sztuka
2CKA006220A0539	Electronic Controls free@home stainless steel - solo	SRL-2-L-866	1	sztuka
2CKA006220A0544	Electronic Controls free@home stainless steel - solo	SRL-2-R-866	1	sztuka
2CKA006220A0536	Electronic Controls free@home stainless steel - solo	SRS-1-866	1	sztuka
2CKA006220A0541	Electronic Controls free@home stainless steel - solo	SRS-2-L-866	1	sztuka
2CKA006220A0545	Electronic Controls free@home stainless steel - solo	SRS-2-R-866	1	sztuka

Kategorie

Produkty niskiego napięcia i systemy → Wiring Accessories - Light Switch Ranges → Frames

